

DOMETIC

HOT PRODUCTS

RANGE

EN Piezo Switch Replacement

Service Kit Instructions

USA & CANADA
Service Office
Dometic Corporation
1120 North Main Street
Elkhart, IN 46514

**Service Center & Dealer
Locations**
Visit: www.dometic.com

Range Models	Field Kit Number and Materials
R31, S31	Visit www.edometic.com for details.

1 Explanation of Symbols and Safety Instructions

This manual has safety information and instructions to help you eliminate or reduce the risk of accidents and injuries.

1.1 Recognize Safety Information

⚠ This is the safety alert symbol. It is used to alert you to potential physical injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

1.2 Understand Signal Words

A signal word will identify safety messages and property damage messages, and it will indicate the degree or level of hazard seriousness.

⚠ WARNING

This indicates a hazardous situation that, if **not** avoided, could result in death or serious injury.

2 Removal


⚠ WARNING: ELECTRICAL SHOCK, FIRE, AND/OR EXPLOSION HAZARD.

Turn off the gas and electrical supplies before removal. Failure to obey this warning could result in death or serious injury.

This section describes how to remove the piezo switch from the existing range or slide-in.

i The images used in this document are for reference purposes only. Components and locations may vary according to specific range or slide-in models.


2.1 Removing the Mounting Screws



1 Removing the Mounting Screws

1. Open the oven door.
2. Remove the two mounting screws from the front of the cooktop in the locations shown.


2.2 Disconnecting the Ignition Wires



2 Disconnecting the Ignition Wires

1. Locate the three ignition wires leading from the piezo switch to the burner heads on the bottom of the cooktop.
2. Gently pull the ignition wires away from the burner heads to disconnect them.

2.3 Removing the Piezo Switch



3 Removing the Piezo Switch

1. Gently pull the piezo switch knob away from the stud to remove it.
2. Remove the two screws securing the piezo switch to the front of the cooktop.
3. Remove the piezo switch and ignition wires from the bottom of the cooktop.

3 Installation

To install the new piezo switch, complete the process described in section 2 in reverse order.