


↗ DOMETIC

REFRIGERATION

RUA SERIES



RUA8408X

EN

Absorption refrigerator
Installation Manual

Please read this instruction manual carefully before installation and first use, and store it in a safe place. If you pass on the product to another person, hand over this instruction manual along with it.



NOTE
You can find details on the operation in the operation manual.

Table of contents

1 Explanation of symbols 3

2 Safety instructions 4

3 Scope of delivery 5

4 Accessories 6

5 Intended use 6

6 Installing the refrigerator 6

7 Connecting the refrigerator 23

1 Explanation of symbols



WARNING!
Safety instruction: Failure to observe this instruction can cause fatal or serious injury.



CAUTION!
Safety instruction: Failure to observe this instruction can lead to injury.



NOTICE!
Failure to observe this instruction can cause material damage and impair the function of the product.



NOTE
Supplementary information for operating the product.

2 Safety instructions

The manufacturer accepts no liability for damage in the following cases:

- Faulty assembly or connection
- Damage to the product resulting from mechanical influences and excess voltage
- Alterations to the product without express permission from the manufacturer
- Use for purposes other than those described in the operating manual



WARNING!

- Never open the absorber unit. It is under high pressure and can cause injury if it is opened.
- Ensure clean and residue-free handling if silicone sealant or similar is used. There is a risk of fire if silicone filaments come into contact with hot parts or naked flames.
- Do not operate the refrigerator if it is visibly damaged.
- If the AC power cable for this refrigerator is damaged, it must be replaced by the manufacturer, customer service or a similarly qualified person in order to prevent safety hazards.
- Never use a naked flame to check the refrigerator for leaks.
- This refrigerator may only be repaired by qualified personnel. Inadequate repairs may cause serious hazards.
- Only use universal LPG gas.
- **Only operate the refrigerator** at the pressure shown on the type plate. Only use pressure controllers with a fixed setting which comply with national regulations.
- Dismantle all refrigerator doors for the disposal of the old refrigerator and leave the shelves in the refrigerator to prevent accidental enclosure and suffocation.



CAUTION!

- Danger of crushing! Do not put your fingers into the hinge.
- Before starting the device, ensure that the power supply line and the plug are dry.



NOTICE!

- Only hold the refrigerator at the body of the refrigerator during transport. Never hold the refrigerator at the absorber unit, the cooling fins, the gas pipes, the door or the control panel.

- Make sure that the refrigerator circuit is not damaged during transportation. The refrigerant in the refrigerator circuit is highly flammable. In the event of any damage to the refrigerator circuit (smell of ammonia):
 - Switch off the refrigerator if applicable.
 - Avoid naked flames and sparks.
 - Air the room well.
- Do not install the refrigerator near naked flames or other heat sources (heaters, direct sunlight, gas ovens etc.).
- **Danger of overheating!**

Always ensure sufficient ventilation so that the heat generated during operation can dissipate. Make sure that the refrigerator is sufficiently far away from walls and other objects so that the air can circulate.
- Check that the voltage specification on the type plate is the same as that of the power supply.
- Do not open the refrigerant circuit under any circumstances.
- Only use the AC connection cable supplied to connect the refrigerator to the AC mains.
- Only use cables with a suitable size.
- Never pull the plug out of the socket by the connection cable.
- The refrigerator may not be exposed to rain.

3 Scope of delivery

- Refrigerator
- Operating manual
- Installation manual

4 Accessories

Available as accessories (not included in the scope of delivery):

Description
LS 300 ventilation grille
3776 gas exhaust vent

All the accessories are available from specialist dealers. If you have any questions, please contact the dealer or your service partner directly.

5 Intended use

The refrigerators are designed for installation in caravans or motorhomes. They are only suitable for cooling and storing foodstuffs. The refrigerators are not intended for the proper storage of medicine.


The refrigerators are designed to be operated on a DC power supply, AC mains power supply or universal LPG gas.

6 Installing the refrigerator

6.1 Preparing the installation

When installing the refrigerator, note the following:


- Ensure that the floor is solid and level.
- Ensure that the refrigerator is level.
- The refrigerator must be installed so that it is easily accessible for service work, easy to de-install and install and can be easily removed from the vehicle.



- The refrigerator must be installed in a recess so that it stands secure when the vehicle is in motion. Note the following dimensions (fig. **1**):

Refrigerator	Overall dimension in mm
Height (A)	1657
Width (B)	550
Depth (C)	677 (excludes control knob 5 mm)

Recess	Dimension in mm
Height (H)	1647 – 1652
Width (W)	530 – 535
Depth (D)	min. 621


Installation with two side vents

**Pos. in
fig. 2, page 8**

Description


- | | |
|---|--|
| 1 | Insulation wool on top and sides of cabinet |
| 2 | Recommended maximum clearance 25 mm |
| 3 | LS300 vent |
| 4 | Minimum height is equal to the height of the cabinet |
| 5 | Dometic gas flue kit 3776 |
| 6 | Air deflection plate |

- The outer wall must be fitted with one air inlet ventilation grille (fig. **2** 3a, page 8) and one outlet ventilation grille (fig. **2** 3b, page 8) so that the heat generated can be easily released to the outside:
 - Lower air inlet vent LS 300 must be installed as flush as possible to the vehicle floor.
 - Upper air outlet vent LS 300 must be installed with the bottom of the vent no lower than equal to the top of the refrigerator cabinet, the bottom of the top vent can be higher than the cabinet.
- Fit an air deflection plate (fig. **2** 6, page 8) above the condenser so that the heat does not accumulate in the vehicle.
- Put insulation wool (fig. **2** 1, page 8) on top and sides of the cabinet.
- If the lower ventilation grille of the air inlet vent cannot be installed flush to the floor, an additional inlet vent (fig. **2** 4, page 8) must be provided in the floor for releasing any possible gas leakage.
- The distance between the refrigerator and the rear wall must be at least 10 mm.



- The recommended maximum distance between the refrigerator and the rear wall is 25 mm. A distance of more than 25 mm between the refrigerator and rear wall leads to poor performance and increases the power consumption of the refrigerator. Reduce the space behind the refrigerator to maximum 25 mm to create adequate air inlet and outlet ventilation corridor (fig. **3**). Use a ventilation plate, for example, to do this.

Installation with one lower side vent and one roof vent




Pos. in
fig. **2**, page 8

Description

1	Insulation wool on top and sides of cabinet
2	Recommended maximum clearance 25 mm
3	LS300 vent
4	Minimum height is equal to the height of the cabinet plus 150 mm
5	Dometic gas flue kit 3776
6	Roof vent

- If the minimum distance between the air inlet and outlet vents cannot be met, a roof vent must be installed instead of the air outlet vent.
 - The roof vent should be installed directly above the back of the refrigerator as far as this is possible. Use an air duct if you need to install the roof vent (fig. **4** 6) offset, otherwise heat will accumulate there.



- If a roof air conditioner is installed, the distance between the roof vent (fig. **5** 1) and the air outlet of the roof air conditioner (fig. **5** 2) must be at least 300 mm.
- The refrigerator must not be installed at the side of the air inlet and outlet vents as this leads to poor performance and increases the power consumption of the refrigerator.
- The air inlet and outlet vents must not be covered by vehicle parts (such as an open door or by installing accessories such as bicycle racks) while operating.
- A separate flue duct must be installed under the air outlet vent, see chapter “Installing the flue duct” on page 19.
- Install the refrigerator so that it is protected from excessive heat, as this leads to poor performance and increases the power consumption of the refrigerator.
- The electrical installation must comply with national and local regulations.
- The gas installation must comply with national and local regulations.
AS 5601.2 – Gas Installations
NZ 5601 – Gas Appliance Safety
- The refrigerator must be installed in a draught-proof location, see chapter “Installing the refrigerator in a sealed location separate to the living space” on page 12.

6.2 Installing the refrigerator in a sealed location separate to the living space

Gas-powered refrigerators in caravans or motorhomes must be installed in a sealed location. This means that the combustion air can not be extracted from the interior and exhaust fumes are prevented from directly entering the living space.


A suitable seal must be provided and fitted between the rear wall of the refrigerator cabinet and the interior of the vehicle. The purpose is to provide a seal between the interior of the vehicle and the cooling unit and ventilation area behind the refrigerator.



WARNING! Fire hazard!

Do not use flammable materials such as silicone sealants, foam or similar for the draught-proof installation.


The manufacturer has applied a sealing strip to the rear surface of the front frame.




- Apply a sealing strip to all four sides of the bottom surface of the refrigerator (1. in fig. 6).
- Push the refrigerator into position (2. in fig. 6). This then seals the space behind the refrigerator to the interior of the vehicle.

OPTIONAL:

- If the refrigerator stands on a platform, install the bottom trim piece in order to seal the space between the refrigerator and the platform.



- Apply a sealing strip (fig. 7 1) to the lower surface of the bottom trim piece.



- Push the bottom trim piece with the four plugs (fig. 8 1) into the holes on the front frame of the refrigerator.
- Snap the three catches (fig. 8 2) into the holes under the bottom frame of the refrigerator.


6.3 Making air inlet and outlet vents



NOTE

At high ambient temperatures, the refrigerator can only provide its maximum cooling capacity if the optimum ventilation has been provided.

- Make a cut out in the wall to fit an appropriate upper and lower vent system, choose LS 300 check the dimensions required for the vent. See chapter “Preparing the installation” on page 6.
- If the lower ventilation grille can not be installed flush to the door, make an air inlet vent in the floor (fig. **2** 4, page 8) behind the refrigerator near the gas burner.

9

- Shield the end of the opening with a deflector to prevent sludge or dirt from getting inside while driving (fig. **9**).


If you have to use a roof vent instead of an upper wall vent:

- Cut out a section in the roof. Refer to the roof vent instruction manual for the required dimensions. When doing so, observe the information, see chapter “Preparing the installation” on page 6.



6.4 Installing the drain water hose

- To avoid damage on the drain water hose, position the hole for the drain water hose in a way, that the hose does not touch the boiler casing.
- Drill a hole through the floor at the rear of the refrigerator.
- Install the drain water hose through the drilled hole. Ensure, that the drain water hose is long enough in order to drain the water outside of the vehicle.
- Ensure that the drain water hose is not kinked.
- Seal the area around the drain water hose.


6.5 Installing the ventilation grille



No. in fig. 10	Description
1	Slider
2	Ventilation grille
3	Installation frame





- Ensure the installation frame is water resistant (fig. **11**).
- Insert the installation frame and screw it down tightly (fig. **12**). Use all the fixing holes for this.





- Fit the ventilation grille (**1.** and **2.** in fig. **13**).
- Insert the slider and lock the ventilation grille with it (**3.** in fig. **13**).

6.6 Install the roof vent




No. in fig. 14	Description
1	Hood
2	Installation frame

► Ensure the installation frame is water resistant (fig. 15).



- Insert the installation frame and screw it down tightly (fig. **16**). Use all the fixing holes for this.
- Insert the hood and screw it down tightly (fig. **17**).


6.7 Installing the flue duct



NOTE

- Install the Dometic gas flue kit 3776. Contact the customer service (see back page).
- Do not install an additional flue stack, as this leads to poor performance and increases the power consumption of the refrigerator.
- Mount the flue duct under the upper ventilation grille (fig. 18 1).

Install the flue duct as follows:




- Make a rectangular opening in the outer wall of the vehicle (fig. **19**).
 - The opening must be as wide as the flue pipe (fig. **18** 3, page 19).
 - The opening must be high enough that the flue pipe fits through at a 45° angle.
- Insert the coil (fig. **18** 7, page 19) in the flue pipe (fig. **18** 8, page 19) of the refrigerator.
- Place the T-piece (fig. **18** 4, page 19) on the adaptor (fig. **18** 5, page 19) and the flue pipe (fig. **18** 8, page 19) of the refrigerator.
- Direct the T-piece at an angle of 45° towards the rear wall.
- Attach the T-piece, adaptor and flue pipe with a screw (fig. **18** 6, page 19).
- Install the mounting plate (fig. **20**).
- Fill the opening with fire-resistant material (e.g. stone wool (fig. **20**)).



NOTE

In some installation situations, it is possible that the flue pipe would extend too far out of the vehicle in its installed state. Shorten the flue pipe to the correct length if necessary.

- Slide the flue pipe at least 15 mm on the T-piece (fig. **20**).



- Attach the cover for the flue stack outside on the vehicle (fig. **21**).

6.8 Securing the refrigerator



CAUTION!


Only screw through the bushes built into the refrigerator, otherwise foamed components, including electrical wiring, can be damaged.



NOTE

Ensure that the screws are tight, even when under increased loads (while driving).

- Push the refrigerator firmly into its final location with the front flange sitting hard against the recess front.



- Push the six screws (fig. 22 1) through the six plastic bushes in the sides of the refrigerator, and fasten into the recess walls.
- Fit the caps (fig. 22 2) into the bushes.

7 Connecting the refrigerator

7.1 Connecting to the gas supply



NOTICE!


- This refrigerator may only be connected to the gas supply by a specialist in accordance with the applicable guidelines and standards.
- Only use cylinders of universal LPG gas fitted with an approved gas pressure regulator. Compare the pressure information on the data plate with the pressure information on the pressure regulator on the gas cylinder.
- **Only** operate the refrigerator at the pressure shown on the data plate.
- **Only** operate the refrigerator with the type of gas shown on the data plate.
- Please note the pressures which are permitted in your country. Only use pressure controllers with a fixed setting which comply with the national regulations.



NOTE


The pressure of the gas supply must be 2.75 kPa. Check the pressure at the test point before using the refrigerator (fig. **23** 1, page 24).

It must be possible to shut off the refrigerator from the gas line separately by means of a shut-off device. The shut-off device must be easily accessible.



- Connect the refrigerator securely to the gas supply (fig. **23**). Always use a back up wrench when loosening and tightening connections.
- Have a leak test and a flame test performed by an authorised specialist after professional installation. Ensure you are issued with a certificate of inspection.

7.2 Connecting the device to electrical power supply



NOTICE!


- The electrical installation and repairs may only be performed by a specialist in accordance with the applicable regulations and standards.
- The device can be connected to 12 V DC and 230 – 240 V AC power supply.
- The respective negative and positive cables of the DC connections for heating and controls may not be joined with one another in a caravan. This can cause electrical interference or damage to electrical components.
- DC connection to the heating element must be made to the vehicle engine battery, connection only while engine is running (fig. 24).



NOTE

- The mains socket must be easily accessible so that you can unplug the power cord if required, thereby disconnecting the refrigerator from the power.
- The plug of the AC connection cable must not be cut off.
- The connection cables must be laid so that they do not come in contact with hot parts of the unit/burner or with sharp edges.
- Changes to the internal electrical installation or the connection of other electrical components (e.g. extra third party fans) to the internal wiring of the refrigerator will void any claims from the guarantee and product liability.

► Connect the device as follows:



Item	Description
1	Connection cable for AC connection
2	Heater 240 V AC
3	Earth for CU
4	Protective Earth
5	Electrode
6	Outer fan 1
7	Fan thermostat
8	Outer fan 2
9	Ignition port
10	Power module
11	Control button
12	Display
13	Inner fan
14	LAC and defrost heater
15	Frame heater
16	Gas valve
17	Temperature sensor
18	Lamp
19	Door sensor
20	Gas inlet
21	12 V DC heater
22	Relay
23	12 V DC vehicle battery connection
24	Thermostat
25	D+ to alternator connection
26	12 V DC house battery connection
27	Thermofuse

AC power

- Connect the refrigerator with the mains plug to an AC socket.

DC power

Please note the following cable sizes:


- 12 V DC vehicle battery connection: $\geq 10 \text{ mm}^2$
 - 12 V DC house battery connection: $\geq 1 \text{ mm}^2$
 - Connection D+: $\geq 0.5 \text{ mm}^2$
 - Total cable length: max. 8 m
- Protect the DC power supply for the 12 V DC heater with 30 A fuse.
 - Protect the DC power supply for controls with 3 A fuse.
 - Run cables to the heating element via a relay or suitable means controlled by an ignition switch to prevent battery from completely discharging, if the engine is switched off (fig. **24**, page 25).
 - Connect vehicle battery cables to the respective plus and minus terminal (fig. **25** 23, page 26).
 - Connect house battery cables to the respective plus and minus terminal (fig. **25** 26, page 26).

D+

In automatic mode, the refrigerator selects the most favourable mode available. The refrigerator is only operated with DC power when the vehicle engine is running. The electronics of the refrigerator uses the signal D+ from the vehicle alternator to detect the running engine.

- Connect the D+ connection to the controls (fig. **25** 25, page 26) with the respective terminal of the vehicle.


7.3 Alternative connection methods for DC power supply



Connection to suit motor home or caravan with the D+ wire connected to the vehicle alternator or ignition switch.


No house battery recharging from the vehicle.

The D+ connection is taken to the vehicle alternator.



Anderson plug controlled by vehicle relay to the ignition switch. Power can only be supplied if the engine is running.


No house battery recharging from the vehicle.



Using a fridge movement switch to add 12 V $\overline{\text{DC}}$ to the D+ connection wire, only when the vehicle is moving.

No house battery recharging from the vehicle.


The D+ is turned on and off via an optional fridge movement switch.



Using a fridge movement switch to add 12 V $\overline{\text{DC}}$ to the D+ connection wire, only when the vehicle is moving. The Anderson plug connection must keep the house battery fully charged.

House battery recharged by vehicle.

The D+ is turned on and off via an optional fridge movement switch.



Anderson plug recharging the house battery via a power diode. The D+ wire can only get a 12 V signal when the battery is being charged.

House battery recharged by vehicle.

The D+ is turned on and off by the vehicle starting and stopping.

AUSTRALIA

Dometic Australia Pty. Ltd.

1 John Duncan Court - Varsity Lakes QLD 4227

☎ 1800 212121 • 📠 +61 7 55076001

Mail: sales@dometic.com.au

dometic.com



AUSTRIA

Dometic Austria GmbH

Neudorferstraße 108

A-2353 Guntramsdorf

☎ +43 2236 908070

☎ +43 2236 90807060

Mail: info@dometic.at

BENELUX

Dometic Branch Office Belgium

Lourdesstraat 84

B-8940 Geluwe

☎ +32 2 3598040

☎ +32 2 3598050

Mail: info@dometic.be

BRAZIL

Dometic DO Brasil LTDA

Avenida Paulista 1754, conj. 111

SP 01310-920 Sao Paulo

☎ +55 11 3251 3352

☎ +55 11 3251 3362

Mail: info@dometic.com.br

DENMARK

Dometic Denmark A/S

Nordensvej 15, Taulov

DK-7000 Fredericia

☎ +45 75585966

☎ +45 75586307

Mail: info@dometic.dk

FINLAND

Dometic Finland OY

Mestariintie 4

FIN-01730 Vantaa

☎ +358 20 7413220

☎ +358 9 7593700

Mail: info@dometic.fi

FRANCE

Dometic SAS

ZA du Pré de la Dame Jeanne

B.P. 5

F-60128 Plailly

☎ +33 3 44633525

☎ +33 3 44633518

Mail: vehiculesdeloisirs@dometic.fr

GERMANY

Dometic WAECO International GmbH

Hollefeldstraße 63 - D-48282 Emsdetten

☎ +49 (0) 2572 879-0

☎ +49 (0) 2572 879-300

Mail: info@dometic-waeco.de

HONG KONG

Dometic Group Asia Pacific

Suites 2207-11 - 22/F - Tower 1

The Gateway - 25 Canton Road,

Tsim Sha Tsui - Kowloon

☎ +852 2 4611386

☎ +852 2 4665553

Mail: info@waeco.com.hk

HUNGARY

Dometic Zrt. Sales Office

Kerekgyártó u. 5.

H-1147 Budapest

☎ +36 1 468 4400

☎ +36 1 468 4401

Mail: budapest@dometic.hu

ITALY

Dometic Italy S.r.l.

Via Virgilio, 3

I-47122 Forlì (FC)

☎ +39 0543 754901

☎ +39 0543 754983

Mail: vendite@dometic.it

JAPAN

Dometic KK

Maekawa-Shibaura, Bldg. 2

2-13-9 Shibaura Minato-ku

Tokyo 108-0023

☎ +81 3 5445 3333

☎ +81 3 5445 3339

Mail: info@dometic.jp

MEXICO

Dometic Mx, S. de R. L. de C. V.

Circuito Médicos No. 6 Local 1

Colonia Ciudad Satélite

CP 53100 Naucalpan de Juárez

Estado de México

☎ +52 55 5374 4108

☎ +52 55 5393 4683

Mail: info@dometic.com.mx

NETHERLANDS

Dometic Benelux B.V.

Ecustraat 3

NL-4879 NP Etten-Leur

☎ +31 76 5029000

☎ +31 76 5029019

Mail: info@dometic.nl

NEW ZEALAND

Dometic New Zealand Ltd.

PO Box 12011

Penrose

Auckland 1642

☎ +64 9 622 1490

☎ +64 9 622 1573

Mail: customerservices@dometic.co.nz

NORWAY

Dometic Norway AS

Østerøyveien 46

N-3232 Sandefjord

☎ +47 33428450

☎ +47 33428459

Mail: firmapost@dometic.no

POLAND

Dometic Poland Sp. z o.o.

Ul. Puławska 435A

PL-02-801 Warszawa

☎ +48 22 414 3200

☎ +48 22 414 3201

Mail: info@dometic.pl

PORTUGAL

Dometic Spain, S.L.

Branch Office em Portugal

Rot. de São Gonçalo nº 1 - Esc. 12

2775-399 Carcavelos

☎ +351 219 244 173

☎ +351 219 243 206

Mail: info@dometic.pt

RUSSIA

Dometic RUS LLC

Komsomolskaya square 6-1

RU-107140 Moscow

☎ +7 495 780 79 39

☎ +7 495 916 56 53

Mail: info@dometic.ru

SINGAPORE

Dometic Pte Ltd

18 Boon Lay Way

06-141 Trade Hub 21

Singapore 609966

☎ +65 6795 3177

☎ +65 6862 6620

Mail: domestic@dometic.com.sg

SLOVAKIA

Dometic Slovakia s.r.o.

Sales Office Bratislava

Nádražná 34/A

900 28 Ivánka pri Dunaji

☎/☎ +421 2 45 529 680

Mail: bratislava@dometic.com

SOUTH AFRICA

Dometic (Pty) Ltd.

Regional Office

South Africa & Sub-Saharan Africa

2 Avalon Road

West Lake View Ext 11

Modderfontein 1645

Johannesburg

☎ +27 87 3530380

Mail: info@dometic.co.za

SPAIN

Dometic Spain S.L.

Avda. Sierra del Guadarrama, 16

E-28691 Villanueva de la Cañada

Madrid

☎ +34 902 111 042

☎ +34 900 100 245

Mail: info@dometic.es

SWEDEN

Dometic Scandinavia AB

Gustaf Melins gata 7

SE-42131 Västra Frölunda

☎ +46 31 7341100

☎ +46 31 7341101

Mail: info@dometicgroup.se

SWITZERLAND

Dometic Switzerland AG

Riedackerstrasse 7a

CH-8153 Rümlang

☎ +41 44 8187171

☎ +41 44 8187191

Mail: info@dometic.ch

UNITED ARAB EMIRATES

Dometic Middle East FZCO

P. O. Box 17860

S-D 6, Jebel Ali Freezone

Dubai

☎ +971 4 883 3858

☎ +971 4 883 3868

Mail: info@dometic.ae

UNITED KINGDOM

Dometic UK Ltd.

Dometic House, The Brewery

Blandford St. Mary

Dorset DT11 9LS

☎ +44 344 626 0133

☎ +44 344 626 0143

Mail: customerservices@dometic.co.uk

USA

Dometic RV Division

1120 North Main Street

Elkhart, IN 46515

☎ +1 574-264-2131