



**FRONT
RUNNER**

AIR CRANE

GVM - 2500KG

WARNING - READ CAREFULLY BEFORE USE

- * Never use the air crane for vehicle maintenance or wheel removal.
- * Always ensure both wheels are chocked opposite to the side being lifted.
- * Always ensure the vehicle is not unstable or able to rollover before using the air crane.
- * Always apply the handbrake before using the air crane.
- * Always ensure the air crane is clear of any sharp or hot objects that could damage the bag.
- * Use the protective mats provided under and above the air crane.
- * All bystanders should be out of the vehicle and clear of the area.
- * Do not over inflate the bag.
- * Be sure not to lift the vehicle to high.
- * Before using recovery equipment the user should have completed an extensive recovery training program.
- * The manufacturer accepts no liability for any injury or damage incurred as a result of incorrect use.

DIRECTIONS FOR USE

- * Carefully place and position the air crane under the vehicle.
- * Use the protective mats provided.
- * Ensure the deflation valve is in a closed position.
- * Push and turn the blue dot 90° to open or 90° to close.
- * Attach compressor to the valve and begin inflating to a SAFE lifting height.
- * To deflate the pneumatic jack push the blue dot on the exhaust valve and turn 90°