



DOMETIC CORPORATION

1120 North Main Street, Elkhart, IN 46514

Please Visit: WWW.DOMETIC.COM

LITERATURE NUMBER MPD 32418

INSTALLATION INSTRUCTIONS

FURNACE REPLACEMENT

CASING CUTOUT AFM-85

Revision A, 10/12/18

Installation Instructions AFM Casing Bottom Discharge

In cases where bottom discharge has been used for 85 the new AFM series needs to be modified for size and location.

This installation instruction is for use only when replacing 8500 series furnace with AFM series.



CAUTION

**ONLY A QUALIFIED TECHNICIAN
MUST REPLACE OR INSTALL UNIT**

REMOVE FURNACE:

1. Remove existing furnace from opening.

INSTALL AFM FURNACE:

1. Remove furnace from box and lay top down
2. Mark on casing bottom per layout drawing the new cutout opening. Make sure to start with a pilot hole in location noted.
3. After hole has been cut install into coach and align with cutout in floor
4. Seal opening with foil tape to insure no air leakage.

