

MPD 90345 2/13
THERMOSTAT KIT 90346
Instructions:
Apply thermal grease (in packet)
to thermostat contact points before
installing.

MPD 90345 2/13
THERMOSTAT KIT 90346
Instructions:
Apply thermal grease (in packet)
to thermostat contact points before
installing.

MPD 90345 2/13
THERMOSTAT KIT 90346
Instructions:
Apply thermal grease (in packet)
to thermostat contact points before
installing.

MPD 90345 2/13
THERMOSTAT KIT 90346
Instructions:
Apply thermal grease (in packet)
to thermostat contact points before
installing.

MPD 90345 2/13
THERMOSTAT KIT 90346
Instructions:
Apply thermal grease (in packet)
to thermostat contact points before
installing.

MPD 90345 2/13
THERMOSTAT KIT 90346
Instructions:
Apply thermal grease (in packet)
to thermostat contact points before
installing.

MPD 90345 2/13
THERMOSTAT KIT 90346
Instructions:
Apply thermal grease (in packet)
to thermostat contact points before
installing.

MPD 90345 2/13
THERMOSTAT KIT 90346
Instructions:
Apply thermal grease (in packet)
to thermostat contact points before
installing.

MPD 90345 2/13
THERMOSTAT KIT 90346
Instructions:
Apply thermal grease (in packet)
to thermostat contact points before
installing.

MPD 90345 2/13
THERMOSTAT KIT 90346
Instructions:
Apply thermal grease (in packet)
to thermostat contact points before
installing.

MPD 90345 2/13
THERMOSTAT KIT 90346
Instructions:
Apply thermal grease (in packet)
to thermostat contact points before
installing.

MPD 90345 2/13
THERMOSTAT KIT 90346
Instructions:
Apply thermal grease (in packet)
to thermostat contact points before
installing.