



INSTALLATION INSTRUCTIONS FOR DOMETIC TRIM PLATE KIT PART NO. 3106462.017

This Trim Plate Kit is intended to be placed against the ceiling of a Recreational Vehicle to cover unsightly marks left from a previously installed Air Conditioner. The Air Conditioner Ceiling Template will hold this Trim Plate in place.

To install, do the following:

1. Follow unit installation instructions through adjusting length of discharge air ducts on the Ceiling Template.
2. Just prior to installation of ceiling template, do the following:
 - a. Place the Trim Plate against the ceiling with textured side facing down and centered over your opening.
 - b. Hold in place with one hand.
 - c. Place ceiling template in place up against the Trim Plate.
 - d. Hand start each unit mounting bolt per installation instructions.
 - e. Tighten each unit mounting bolt until it is snug against ceiling template.
 - f. Adjust Trim Plate to make square with walls of RV.
 - g. Complete tightening mounting bolts per installation instructions.
 - h. Return to the unit installation instructions and complete installation of Air Conditioner.
3. For most installations, the Trim Plate will lay flat against the ceiling and no further steps are necessary. However, we have found in some installations, due to ceiling curvature or panel trim material, screws may be required to hold the plate flat to the ceiling. You may use any type of sharp pointed screw to drive through the plate and into your ceiling.

