



# 3106738.002 INSTRUCTIONS FOR MOUNTING MANUAL LIGHT SWITCH KIT

## THIS KIT CONTAINS:

|     |             |              |     |             |                |
|-----|-------------|--------------|-----|-------------|----------------|
| (1) | 3106739.000 | Bulb, 5W     | (1) | 3106747.003 | Support, Front |
| (1) | 3106740.008 | Brown Wire   | (1) | 2004044109  | Cover          |
| (1) | 3106741.006 | Yellow Wire  | (1) | 2004043002  | Shade          |
| (1) | 3106742.004 | Yellow Wire  | (1) | 2931049015  | Switch         |
| (1) | 3106743.002 | Brown Wire   | (1) | 2930744012  | Light Base     |
| (1) | 3106744.000 | Wire Nut     | (1) | 2930611013  | Cover Plate    |
| (1) | 3106745.007 | Instructions | (1) | 2940825009  | Switch         |
| (1) | 3106746.005 | Template     | (1) | 2943241.014 | Cap            |

## GENERAL INSTRUCTIONS

All field wiring modification should be made in compliance with the latest edition of ANSI/NFPA NEC and ANSI A119.2 for Recreational Vehicles.

Installation of this Switch Kit allows the continuous operation of the interior light. The light provides sufficient heat to require operation of the cooling system which will keep the food in the freezer frozen.



**THIS UNIT MUST BE SERVICED BY A QUALIFIED TECHNICIAN. MODIFICATION OF THE APPLIANCE CAN BE EXTREMELY HAZARDOUS AND COULD LEAD TO SERIOUS INJURY OR DEATH.**

**Place these instructions with the Owner's Manual for future reference.**

**READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLING THIS KIT.**

## INSTALLATION INSTRUCTIONS

1. Remove the existing light housing by sliding the light lens toward the rear of the cabinet. Remove the one screw and slide the light housing toward the rear of the cabinet until the front holding tab comes out and the housing is free of the liner.

2. Cut the terminal off of the long red, blue or black wire and strip the end 3/8".

3. Take the correct template for your model and place the square hole in the template directly over the square hole in the plastic liner. Use something pointed (like an awl, nail, etc.) and make a prick-mark at the two locations indicated.

**NOTE: New holes not required on RM7030, RM7130, RM7732 and RM7832.**

4. Remove the template and drill a 1/16" dia. hole at each location.

5. Remove the peel strip and install the plastic front support using the front 1/16" dia. hole as a locator, as shown in Figure 1.

**NOTE: Not required on RM7030, RM7130, RM7732 and RM7832.**

FIGURE 1



