



A&E Systems

Installation Instructions

Kit, Top Adapter 4.88 Radius Two Step Awning Part No. 3108907.027

For 76000XX.400 Hardware

This Kit Contains:

2 - 3108907.035	Adapter, Top 4.88" Radius
4 - 3108708.094	1/2" Foam Spacer
2 - 3109506.109	Spacer, Bottom Bracket
4 - 3104499.045	Screw, S14-10 x 1" HHW
4 - 3104176.072	Screw, Hexcap 1/4-20 x 2.5" SS
4 - 317534.006	Nut, Lock w/Insert 1/4-20 SS
1 - 3109951.008	Installation Instructions

Important: Read and understand all of the following steps before beginning installation.

This kit is designed to fit a 4.88" side wall radius for the top mounting bracket and will space the hardware 1/2" from side wall. Follow the installation instructions provided with the hardware and add the following steps:

1. Before installing hardware, mount the 4.88" radius top adapter to the top mounting bracket using the 2" x 1/4-20 screws and 1/4-20 lock nut provided with this kit.
2. Place two foam spacers on each back channel at positions shown in FIG. 1. Bottom spacer will be located at bottom of back channel. Middle spacer will be located directly behind strut bracket pin.
3. With the top radius adapter secured on the top mounting bracket, hold the arm assembly at desired position and mark location of holes in top adapter. Secure top adapter to side wall using two (2) 1" x S14-10 screws provided with this kit.

Important: Structural backing is required where mounting screws will be installed through side wall for securing top adapter.

4. Before securing the bottom mounting bracket to side wall, place one bottom bracket stand off in position as shown in FIG. 1. Use the 2-3/4" upper bracket screws supplied with hardware.

5. Place cover plate supplied with hardware on bottom mounting bracket. Repeat on opposite side.

FIG. 1

