

CAMPER JACK BRACKET ACCESSORY

USA

SERVICE OFFICE
Dometic Corporation
2320 Industrial Parkway
Elkhart, IN 46516
574-294-2511

CANADA

Dometic Corporation
46 Zatonski, Unit 3
Brantford, ON N3T 5L8
CANADA
519-720-9578

For Service Center
Assistance Call:
800-544-4881

 WARNING

This manual must be read and understood before installation, adjustment, service, or maintenance is performed. This unit must be installed by a qualified service technician. Modification of this product can be extremely hazardous and could result in personal injury or property damage.

 AVERTISSEMENT

Lire et comprendre ce manuel avant de procéder à l'installation, à des réglages, de l'entretien ou des réparations. L'installation de cet appareil doit être effectuée par un réparateur qualifié. Toute modification de cet appareil peut être extrêmement dangereuse et entraîner des blessures ou dommages matériels.

INSTRUCTIONS

CAMPER JACK BRACKET ACCESSORY

Straight Bracket Kit	3105638.005
Combination Kit	3105638.013
Angle Bracket Kit	3105639.003

REVISION:

Form No. 3105646.024 8/06
(Replaces 3105646.016)
(French 3310919.000)
©2006 Dometic Corporation
LaGrange, IN 46761

SAFETY INSTRUCTIONS

This manual has safety information and instructions to help users eliminate or reduce the risk of accidents and injuries.

RECOGNIZE SAFETY INFORMATION



This is the safety-alert symbol. When you see this symbol in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating instructions.

UNDERSTAND SIGNAL WORDS

A signal word, **WARNING** OR **CAUTION** is used with the safety-alert symbol. They give the level of risk for potential injury.

⚠ WARNING Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

⚠ CAUTION Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

CAUTION When used without the safety alert symbol indicates, a potentially hazardous situation which, if not avoided, may result in property damage.

Read and follow all safety information and instructions.

GENERAL INSTRUCTIONS

⚠ WARNING

These instructions must be read and understood before installation of this kit. This kit must be installed by a Dometic Service Center or a qualified service technician. Modification of this product can be extremely hazardous and could result in personal injury or property damage.

A. GENERAL INSTRUCTIONS

These instructions should be used in conjunction with those packed with the awning. Install awning per the installation instructions packed with the product. When it references locating and mounting the awning foot use the following instructions:

Contents:

- | | |
|---------------------------|-----------------------|
| (2) Mounting Brackets | (8) 5/16" Nuts |
| (2) Clamps | (2) Gaskets |
| (8) 5/16" X 1-1/4" Bolts | (2) 1-7/8" Dia. Shims |
| (12) 5/16" x 7/8" Washers | (4) 7/8" Long Spacers |
| (8) 5/16 Lock Washers | |

B. INSTALLATION PROCEDURE

1. Determine the position of brackets per awning length. Multiple camper bracket locations are possible depending on awning length and jack position on the truck camper.

Note: Use appropriate shims and spacers as noted below.

2. Place gasket on clamp as shown.
3. Place one (1) clamp around each jack and loosely attach using two (2) 5/16" bolts, washers, lock washer and nuts.
4. Install awning per installation instructions. Install stop bolts in approximate location and place awning foot in bottom bracket.

5. Install awning bottom bracket with 5/16" bolts, washers, lock washers and nuts to camper jack bracket and tighten nuts to finger-tight.
6. With awning in the stored position, adjust mounting foot to ensure awning arms are straight and parallel to the coach. Tighten bottom bracket bolts. Adjust camper brackets if necessary. Tighten camper bracket bolts.
7. Lift up on lift handle and raise awning to clear top brackets. Remove stop bolts and reinstall to maintain clearance between top casting and top bracket.
8. Confirm that arm is not resting on upper brackets, arm are straight and parallel. Open and close the awning to ensure smooth operation.

Note: On some campers that have rear skirts the awning mounting brackets and /or camper brackets can be attached as long as adequate backing material has been previously installed. Use awning foot mounting screws which are included with the awning hardware.

