



Electrolux

TRIM LINE

TRIM LINE AWNING MODELS:

AT210.001X

AT240.001X

AT270.001X

AT300.001X

AT330.001X

AT360.001X

INSTALLATION & OPERATING INSTRUCTIONS

MODELS

AT210.001X

AT240.001X

AT270.001X

AT300.001X

AT330.001X

AT360.001X

APPLICATION:

The Trim Line Awning is designed and intended for mounting on pop-up tent trailers and pickup campers.

IMPORTANT: Read the entire installation procedure before starting the installation.

NOTE: The Dometic Corporation assumes no liability for damages or injury resulting from installation or operation of this product.

I.A. Install vinyl welt of awning bag into awning rail by inserting vinyl welt into one end of awning rail and sliding awning into position. (See FIG. 1 .A)

B. If the awning is to be left mounted during travel, secure each end by drilling a 7/64" diameter hole and installing a #6x 5/8" sheet metal screw in each end. (See FIG. 1 .B)

NOTE: If the awning is installed above the door, Door Roller Kit (Part No. 930004) may be installed to prevent damage to fabric.

NOTE: When unzipping bag or untying poles, be sure to hold poles so loose poles do not fall out of the bag.

2. Unzip bag and untie and remove poles from bag.
3. Undo velcro strap and unroll awning fabric.
4. Insert pin of rafter pole through the eye of the adjustable pole and through hole on the roller tube. (See FIG. 4).
5. Repeat Step 4 on the other side of the awning.
6. Compress the rafter pole and place the end of the rafter against the side of the camper, directly under the edge of the fabric. (See FIG. 6)
7. Repeat Step 6 on the other side of the awning.
6. To raise awning, twist lower adjustable pole while holding upper pole and raise awning to desired height. Twist lower pole to lock in position. (See FIG. 8). **NOTE:** If application requires longer adjustable poles, order Kit No. 3104264.001 from your Dealer.

NOTE: The wire tie-down loops are provided in the adjustable poles if you desire to tie the awning down to tent stakes (provided in the hardware bag).

9. To close awning, reverse Steps 2 through 8.)**NOTE:** During rain, awning should be closed or one end lowered to allow water to run off.
10. After rolling up the awning fabric, use velcro strap to hold awning in place while storing the poles. Zip one end of the bag 1/3 closed and slide the poles into that end of the bag. Now tie the free end of the poles with the end tie strap. Now unzip the bag and tie the other end strap. Zip the bag closed.

