

START HERE!

READ ME FIRST

Don't be a hero and muscle through this installation without reading these fitting instructions first! Improper installation of this gear may void certain aspects of your warranty.


Before you begin, take a moment and open all your Front Runner rack kit boxes and gather the assembly instructions for the various components.

A complete kit will contain:

1. A Front Runner Mounting System specific to your vehicle
2. A Front Runner Rack Tray or Load Bar Slats

This document will guide you through the assembly of the mounting system and assist you in fitting the roof rack tray or load bars to your specific vehicle.

Please refer to the next page for a list of all the components, quantities and tools required.



IMPORTANT WARNING! ⚠



IT IS CRITICAL THAT ALL FRONT RUNNER PRODUCTS BE PROPERLY AND SECURELY ASSEMBLED AND ATTACHED TO YOUR VEHICLE. IMPROPER ATTACHMENT COULD RESULT IN AN AUTOMOBILE ACCIDENT, AND COULD CAUSE SERIOUS BODILY INJURY OR DEATH. YOU ARE RESPONSIBLE FOR ASSEMBLING AND SECURING ALL FRONT RUNNER PRODUCTS TO YOUR VEHICLE, CHECKING THE ATTACHMENTS PRIOR TO USE, AND PERIODICALLY INSPECTING THE PRODUCTS FOR ADJUSTMENT, WEAR AND DAMAGE. THEREFORE, YOU MUST READ AND UNDERSTAND ALL OF THE INSTRUCTIONS AND PRECAUTIONS SUPPLIED WITH YOUR FRONT RUNNER PRODUCT PRIOR TO INSTALLATION OR USE. IF YOU DO NOT UNDERSTAND ALL OF THE INSTRUCTIONS AND CAUTIONS, OR IF YOU HAVE NO MECHANICAL EXPERIENCE AND ARE NOT THOROUGHLY FAMILIAR WITH THE INSTALLATION PROCEDURES, YOU SHOULD HAVE THE PRODUCT INSTALLED BY A PROFESSIONAL INSTALLER OR OTHER QUALIFIED PERSONNEL.

NOTE: Front Runner will not be responsible for any damage caused by the failure to install the product according to these instructions.


Please call us if you have any questions about the installation of this product.

**1 GET ORGANIZED****IN THE BOX**

1	2 X	Foot Rail - 1 LH & 1 RH
2	4 X	Stiffener Bracket
3	7 X	Narrow Slat - 1159mm Long
4	8 X	Aluminium Spacer - 18mm High
5	4 X	Aluminium Spacer - 20mm High
6	8 X	M6 x 16 Button Head Flanged Bolt
7	8 X	M6 Nyloc Nut
8	20 X	M6 Nut Cap
9	28 X	M6 x 25 Button Head Thread Forming Screw
10	12 X	M6 x 20 x 2 Flat Washer
11	12 X	M6 x 45 Hex Bolt
12	12 X	M6 Jack Nut
13	1 X	Jack Nut Tool
14	1 X	M6 x 12 x 1 Flat Washer
15	1 X	M6 x 12 Button Head Bolt

TOOLS NEEDED**FIGURE 1.1**

2.1



Secure the Stiffener Brackets (Item 2) to the Foot Rails (Item 1), using M6 x 16 Button Head Flanged Bolts & M6 Nyloc Nuts (Items 6 & 7). Fully tighten.


Do this to both the LH & RH Foot Rails.

Place M6 Nut Caps (Item 8) over all Nyloc Nuts.

Tightening Torque:

M6 : 8-10Nm / 5.9 ft lb - 7.38 ft lb

2.2



NOTE: Do not fit the front and middle slats yet.

Use a little Oil / Anti-Seize on screw threads before inserting. Note these are Thread forming screws.

Assemble five Slats (Item 3) to the Foot Rails using M6 x 25 Thread Forming Screws (Item 9).

Tightening Torque 8-10Nm / 5.9 ft lb - 7.38 ft lb. Take care when using a cordless driver.

Using a Panel Tool, carefully remove the ditch trim on each side.

Starting at the top edge of the windscreen measure 235mm along the ditch towards the rear of the vehicle. Mark the hole centre in the ditch as shown.

Place the rack on the roof, lining up the front slot centre with the mark you made and mark the centre of the remaining 5 slots. Do this on both the LH & RH side and remove the rack from the vehicle.

TIP: Use a drill stop or tape around the drill to mark a depth of 10mm. Some models may have an airbag curtain below.


Use the 20mm forstner bit on the marks made earlier. This will start the pilot hole and remove the seam sealer to allow the jack nut to seat correctly. (Take care not to scratch the ditch paint but only remove the seam sealer)

A craft knife can also be used after a 6mm pilot hole is drilled using the spacer as reference.


Drill a 6mm Pilot hole in the center of the markings. Open the holes using a 12mm drill bit.

Apply anti rust to all holes.

2.3



2.4




Insert a M6 x 25 Button Head Bolt and a M6 x 12 x 1 Flat Washer (Items 15 & 14) into the Jack Nut Tool (Item 13) and loosely fit a Jack Nut (Item 12) to the Button Head Bolt as shown.

Using a cordless driver and a 4mm allen cordless bit, set the Jack Nut into the hole while holding the Jack Nut Tool, to prevent the Jack Nut from turning.



Make sure the Jack Nut has pulled up all the way to the inside skin of the roof panel.

2.5



Clean each mounting point with denatured alcohol. Apply waterproof silicone over each for the holes.

Center the spacers (Items 4 & 5) over each of the holes, followed by the rack assembly.



Front Foot - 2 x 18mm Spacers
Middle Foot - 2 x 20mm Spacers
Rear Foot - 2 x 18mm Spacers


Place a bead of silicone on the threads of the M6 x 45 Hex Bolts and secure using M6 x 45 Hex Bolts & M6 x 20 x 2 Flat Washers (Items 11 & 10). Fully tighten.

Place M6 Nut Caps (Item 8) over all Hex Bolts.



Tightening Torque:

M6 : 8-10Nm / 5.9 ft lb - 7.38 ft lb



Use a little Oil / Anti-Seize on screw threads before inserting. Note these are Thread forming screws.




Once the rack is centered and tightened down, assemble the middle Slat (Item 3) to the Foot Rails using M6 x 25 Thread Forming Screws (Item 9).



Tightening Torque 8-10Nm / 5.9 ft lb - 7.38 ft lb. Take care when using a cordless driver.

2.7


STANDARD WIND FAIRING ASSEMBLY



Refer to fitment guide RRAC356

2.8

LIGHT BAR WIND FAIRING ASSEMBLY



Refer to fitment guide RRAC357

3

INSTALL OTHER VEHICLE AND RACK ACCESSORIES

Now's the time to visit your favorite Front Runner dealer in person or online.

IMPORTANT!

FRONT RUNNER RACK KITS OFTEN HAVE A HIGHER LOAD RATING THAN THE VEHICLES THEY ARE MOUNTED TO. PLEASE REFER TO YOUR SPECIFIC VEHICLE MANUFACTURER FOR A RECOMMENDED ROOF RATING. FRONT RUNNER CANNOT BE RESPONSIBLE FOR IMPROPER LOADING BEYOND THE VEHICLE MANUFACTURER'S STATED LOAD CAPACITY.

Be sure to tag us. We love to see our gear in action! #FrontRunnerOutfitters #BornToRoam

Share your adventures on:

