



For Models: 947500.006 947500.007
9470XX.003 9471XX.003

The following design changes have taken place. Please substitute the appropriate sections in the Installation Instructions.

Step 6, Figure 5, Page 3: Use 3/8" drill bit in place of 5/16" drill bit.

Step 8, Figure 8, Pages 3 & 4: Snap buttons have been replaced with Common Sense Fasteners. Mark locations and drill holes exactly as stated in the instructions for the snaps.

In some applications, more tension may be required on the spring pole assembly. If this is the case, two additional rubber tips are supplied to add length to the poles.

To install, remove the existing WHITE TIP and replace with GRAY TIP which is included in the parts bag.

