



# Box # 5

## ALUMAROOM Accessory Kit

### AR05.ACC14

### Inventory Check Sheet

INSTALLER:

PLEASE INVENTORY YOUR ACCESSORY KIT BEFORE YOU START THE ASSEMBLY OF YOUR DOMETIC ALUMAROOM. CHECK THE QUANTITIES OF EACH ITEM AND CHECK OFF THE BOXES TO THE LEFT WHEN YOU VERIFY THE INVENTORY.

Installer  
Check  
Sheet

<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>QTY</u>	<u>U/M</u>
<b>AR05.ACC14</b>	<b>KIT, ACCESSORY 14' 8" ROOM</b>		
3313373.015	SKIRT, MAIN 3PNL+1DR WHITE	1	EA
3313374.005	SKIRT, WHEEL WELL WHITE	1	EA
3313372.009	SKIRT, UPPER SIDE WHITE	2	EA
3313480.000	HANDLE, DOOR	2	EA
3313431.003	CHANNEL, RAFTER END 2.75"	6	EA
3313432.001	SPACER, NYLON 1/20D X 1/4L	14	EA
310359.016	SCREW, D 8-18 X 1.00 HHW	14	EA
309513.033	WASHER, STEEL .197 X .50 X .05	4	EA
3308964.018	SCREW, S #6-20 X .50 FHCR	6	EA
3313533.001	SCREW, WOOD PAN PHIL #8 X .75	32	EA
3313467.007	TAPE, DUCT ROLL WHITE	1	EA
3313398.004	DUAL LOCK, SJ3550 250 .50" BLACK	156	INCH
3313529.004	INSULATION, PIPE 3/4C 3/8T 72L	6	EA
3313534.XXX	INSTALL INSTR: ALUMAROOM	1	EA
3314948.XXX	WARRANTY, ALUMAROOM	1	EA

Form No. 3313536.014

©Dometic, LLC

LaGrange, IN 46761

Issued: 2012-06

PR Ref: 12015L

This document should be printed 2-sided on one 8 1/2" x 11" sheet.



## BOX #5 ACCESSORY KIT PACKING INSTRUCTIONS

1. Locate (3) small clear plastic bags. Lay them out so that you can place items in each one. Using the left column of the items listed below place the items in each bag as follows:
  - a. Put the 2 door handles in the first bag. Seal the bag closed. Set aside for packing into the main carton.
  - b. Put 6 channel rafter ends, 14 spacers, and 14 (310359.016) screws in the second bag. Seal the bag closed. Set aside for packing into the main carton.
  - c. Put 4 steel washers, 6 (3308964.018) screws, and 32 (3313533.001) screws in the third bag. Seal the bag closed. Set aside for packing into the main carton.
2. Locate (1) large clear plastic bag. Locate the 156" piece of Dual Lock™, roll it into a roll and put it into the plastic bag. Seal the bag closed. Set aside for packing into the main carton.
3. Locate a 2<sup>nd</sup> large clear plastic bag. Place the sealed plastic bags with their contents from steps 1 and 2 into the bag. Place the duct tape roll in the bag. Place the installation instructions and warranty in the bag. Seal the bag closed.
4. Locate the 12 x12 x 48 inch carton. Fold the carton into shape, fold over the box ends on **only** one end of the formed box and tape this box end closed. Turn the box over and open the other box end flaps so that the box can be packed.
5. Starting at the top of the inventory list below pack the box in the order of the items shown on the inventory list down to the carton. As you pack each item check it off of the sheet in the space provided in the left column.

Packing Check List	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>QTY</u>	<u>U/M</u>
	<b>AR05.ACC14</b>	<b>KIT, ACCESSORY</b>	<b>14' 8" ROOM</b>	
	3313373.015	SKIRT, MAIN 3PNL+1DR WHITE	1	EA
	3313374.005	SKIRT, WHEEL WELL WHITE	1	EA
	3313372.009	SKIRT, UPPER SIDE WHITE	2	EA
	315931.010	BAG, PLASTIC 4 X 8	3	EA
	3313480.000	HANDLE, DOOR	2	EA
	3313431.003	CHANNEL, RAFTER END 2.75"	6	EA
	3313432.001	SPACER, NYLON 1/20D X 1/4L	14	EA
	310359.016	SCREW, D 8-18 X 1.00 HHW	14	EA
	309513.033	WASHER, STEEL .197 X .50 X .05	4	EA
	3308964.018	SCREW, S #6-20 X .50 FHCR	6	EA
	3313533.001	SCREW, WOOD PAN PHIL #8 X .75	32	EA
	315931.003	BAG, PLASTIC 9.5 X 13.5	2	EA
	3313467.007	TAPE, DUCT ROLL WHITE	1	EA
	3313398.004	DUAL LOCK, SJ3550 250 .50" BLACK	156	INCH
	3313529.004	INSULATION, PIPE 3/4C 3/8T 72L	6	EA
	3313534.XXX	INSTALL INSTR: ALUMAROOM	1	EA
	3313536.014	CONTENTS SHEET: AR05.ACC14	1	EA
	3313584.009	CARTON 12 X 12 X 48	1	EA
	3313530.005	LABEL, 1-LINE "BOX 5"	2	EA
	3313590.006	DECAL, DOMETIC LOGO	2	EA
	3311956.000	LABEL, PACKAGE BY SUPPLIER	1	EA
	3314948.XXX	WARRANTY. ALUMAROOM	1	EA

6. When the items on the sheet down to the carton (including this sheet) have been packed into the box and the check list is checked down to the carton, close the flaps on the box and tape it closed.
7. Place a Dometic logo label centered on each box side. Place the package by supplier label on one carton end.
8. On the same carton end place one "Box 5" labels, and the second "Box 5" label on one carton side near the end.