

•Installation •Operation •Maintenance

Effective 9/1/2014

SAFETY ALERT SYMBOLS

Safety Symbols alerting you to potential personal safety hazards.
 Obey all safety messages following these symbols.



**FOR YOUR SAFETY READ ALL INSTRUCTIONS
 BEFORE INSTALLATION AND OPERATION**

When properly installed and used the Stove Wrap is a non-flammable, washable and reusable high quality fabric which will keep your range and cooktop free of cooking drips, spills, splatters and those hard to clean burnt on messes.



PERSONAL INJURY/PROPERTY DAMAGE

- **Failure to place and use Stove Wrap as directed could cause personal injury or damage to your stove or stove top.**
- **DO NOT place Stove Wrap if stove is on, serious injury can occur.**
- **DO NOT place directly on heating element or open flame, will damage liner.**
- **If Stove Wrap does come in contact with a direct flame, it will not ignite but will suffer burn damage.**
- **DO NOT place or cook food directly on Stove Wrap.**
- **DO NOT use on any manufacturer's product other than the one that is specified on the package.**
- **DO NOT cut, tear or try and modify in any way the Stove Wrap liner.**
- **DO NOT wash with bleach or other harsh chemical.**

INSTALLATION

1. Remove all packaging and discard.
2. When your stove top grates are cool, remove grates from top of your stove.
3. Place Stove Wrap on stove top and align the 3 large holes around each burner and make sure holes lie flat on stove top and under burners.
4. Stove Wrap has 4 silver grommets to secure placement. Align grommets in each corner with black rubber grommets on your stove top.
5. Replace grates by making sure the feet of the grates go through the silver Stove Wrap grommets and the black rubber grommets on your stove top.
6. Once the grates are secure in the grommet holes, Stove Wrap is now secure.
7. Prior to every use confirm that the Stove Wrap has not moved out of place.
8. You are now ready to start cooking.

After installing Stove Wrap, please make sure it is lying flat on the cooktop. Check burner heads to make sure they are straight, and if not, adjust them so that the flame does not come into contact with the Stove Wrap.

CARE AND CLEANING

1. It is important to clean Stove Wrap regularly to prevent the buildup of grease, oils, or food spills.
2. After cooking, if Stove Wrap is soiled, remove Stove Wrap once your stove top grates have cooled to touch. Once removed, place soiled Stove Wrap in washing machine and wash on regular wash cycle. If grease or oils are present please wash Stove Wrap separately.
3. After washing you can lay out to dry or place in dryer until dry.

ATWOOD® STOVE WRAP WARRANTY

Atwood Mobile Products warrants to the original owner this product will be free of defects in material and workmanship for a period of one (1) year from the date of purchase. Atwood's liability hereunder is limited to the replacement of product at the discretion of the manufacturer. The warranty is void if the product has been damaged by accident, unreasonable use, neglect, tampering or other causes not arising from defects in material or workmanship. The warranty extends to the original consumer purchaser of the product only, and is subject to the following conditions:

1. For one (1) years commencing with the date of purchase, Atwood will provide the replacement of any Stove Wrap that is found to be defective by Atwood in material or workmanship.
2. In the event of a warranty claim, the Original Owner must contact the Atwood Consumer Service Department, 1120 North Main, Elkhart, IN 46514, telephone: 866-869-3118, fax: 574-206-9655. Warranty claim service must be performed as approved by the Atwood Consumer Service Department. Warranty replacement Stove Wrap will be furnished freight prepaid. The replaced warranty products become the property of Atwood Mobile Products and must be returned to the Atwood Consumer Service Department freight prepaid, unless prior arrangements have been agreed to.
3. This warranty is valid only when the product is applied, installed, maintained and operated in accordance with this Atwood Installation, Maintenance and Operating Manual. Any deviation from these recommended specifications must be approved in writing by Atwood.
4. ANY IMPLIED WARRANTIES ARE LIMITED TO THE DURATION OF THIS WARRANTY AS STATED ABOVE. THERE ARE NO OTHER WARRANTIES THAN THOSE EXPRESSLY STATED HEREIN.

SERVICE CALLS AND QUESTIONS

Location and phone numbers of qualified Service Centers can be found at our website <http://www.askforatwood.com> or call 866.869.8116 to locate a Service Center.