


CAB COMFORT

HEAT PUMP FOR SEMI-SLEEPER



Pre-Wired for Auxiliary Heat Option

USA
SERVICE OFFICE
The Dometic Corp.
509 South Poplar Street
LaGrange, IN 46761
219-463-4858

CANADA
Dometic Dist.
866 Lings Dr.
Cambridge, Ontario
CANADA N3H 2N7
519-653-4390

**For Service Center
Assistance Call:**
800-544-4881

PARTS LIST

MODEL
42044.502
42055.502

MODELS 42044.502 AND 42055.502 CAB COMFORT A/C

Index #	Description	42044.502	42055.502
1	Electrical Box Cover	3108284.005	3108284.005
2	Condenser Blower Motor & Housing Compl. Includes Capacitor & Blower Wheel	3108202.007	3109049.001
3	Evaporator Blower Motor & Housing Compl. Includes Capacitor & Blower Wheel	3108201.009	3108201.009
4	AC Power Module Board	3106482.015	3106482.015
5	Transformer 120V/12V	3108074.018	3108074.018
6	Solenoid Coil	3105504.009	3105504.009
7	Reversing Valve Weldment	3108607.015	3108607.015
8	PC Board Standoff (4 req.)	3101624.017	3101624.017
9	PC Board Support (6 req.)	3101623.019	3101623.019
10	Strain Relief	302994.017	302994.017
11	Ambient Sensor 48"	3106483.021	3106483.021
12	Field Wiring Decal	3108302.013	3108302.013
13	Compressor Grommet (3 req.)	3100238.215	3100238.215
14	Flange Nut 5/16-18 (3 req.)	306342.002	306342.002
15	Nut, Hex MS #10-32 (4 req.)	311260.001	311260.001
16	Clamp, Worm Drive	3107614.004	3107614.004
17	Power Cable	3107330.031	3107330.031
18	Control Cable	3106614.013	3106614.013
19	Clip, U Type #10-24 (4 req.)	3108299.003	3108299.003
20	Reversing Valve Harness	3105505.022	3105505.022
21	Gasket	3100286.032	3100286.032
22	Snap-In Bushing	301028.042	301028.042
23	Snap-In Bushing	301028.041	301028.041
24	Filter with Hook Tape	3108707.328	3108707.328
25	Capacitor Strap	317188.000	317188.000
26	Motor Starter	3107977.005	3107977.005
27	Duct Connector	3108228.002	3108228.002
28	Insulated Flex Duct (4' req.)	3108421.003	3108421.003
29	Compressor Mtg. Sleeve (3 req.)	3100239.155	3100239.155
30	Compressor - Reversing Valve Spacer	3100239.155	3100239.155
31	Compressor Assembly	3107323.002	3109048.011
32	Terminal Cover	3105581.007	3105581.007
32	Terminal Cover Gasket	3102549.007	3102549.007
34	Terminal Cover Nut	3102550.005	3102550.005
35	Gasket, Nut	3102551.003	3102551.003
36	Overload Protector	3100250.350	3100250.392
37	Overload Spring	3102552.001	3102552.001
38	Comfort Control Center	3106463.007	3106463.007
39	Capillary Tube	3108303.003	3108303.003
40	Evaporator Coil	3109114.003	3109114.003
41	Condenser Coil	3109115.000	3109115.000
42	Capacitor	3100248.305	3100248.305
43	Rotating Vent (1 req.)	3106970.019	3106970.019
Customer Option Not Required:			
	Auxiliary Heat Kit	3108868.005	3108868.005

