


DOMETIC

AWNINGS

TRIM LINE SCREEN ROOM



9672XX.010

EN

Trim Line Screen Room

Installation and Operation Manual 2

Service Center & Dealer Locations
Visit: www.dometic.com

Read these instructions carefully. These instructions **MUST** stay with this product.

Contents

1	Explanation of Symbols and Safety Instructions	2
1.1	Recognize Safety Information	2
1.2	Understand Signal Words	2
1.3	Supplemental Directives	3
1.4	General Safety Messages	3
2	General Information	3
3	Intended Use	4
4	Installation	4
4.1	Open the Trim Line Awning	4
4.2	Position the Screen Room	4
4.3	Install the Front Panels	5
4.4	Install the Side Panels	5
4.5	Fasten the Screen Room to the Camper	5
4.6	Attach the Rear Skirt	6
4.7	Secure the Screen Room to the Ground	6
4.8	Mount the Wheel Cover	6
5	Operation	7
5.1	Use the Privacy Panels	7
5.2	Store the Screen Room	7
6	Disposal	7
	Limited One-Year Warranty	8
	Customer Support	9

1 Explanation of Symbols and Safety Instructions

This manual has safety information and instructions to help you eliminate or reduce the risk of accidents and injuries.

1.1 Recognize Safety Information

 **This is the safety alert symbol.** It is used to alert you to potential physical injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

1.2 Understand Signal Words

A signal word will identify safety messages and property damage messages, and will indicate the degree or level of hazard seriousness.

 **DANGER!**
Indicates a hazardous situation that, if **not** avoided, will result in death or serious injury.

 **WARNING**
Indicates a hazardous situation that, if **not** avoided, could result in death or serious injury.

 **CAUTION**
Indicates a hazardous situation that, if **not** avoided, could result in minor or moderate injury.

NOTICE: Used to address practices **not** related to physical injury.

 Indicates additional information that is not related to physical injury.

1.3 Supplemental Directives

To reduce the risk of accidents and injuries, please observe the following directives before proceeding to install or operate this appliance:

- Read and follow all safety information and instructions.
- Read and understand these instructions before installation or operation of this product.
- The installation must comply with all applicable local or national codes, including the latest edition of the following standards:

U.S.A.

- ANSI/NFPA70, National Electrical Code (NEC)
- ANSI/NFPA 1192, Recreational Vehicles Code
- ANSI Z21.57, Recreational Vehicles Code

Canada

- CSA C22.1, Parts I & II, Canadian Electrical Code
- CSA Z240 RV Series, Recreational Vehicles

1.4 General Safety Messages

DANGER! CARBON MONOXIDE POISONING.

Do not operate any appliances (gas, combustion, etc.) venting into the screen room enclosure with the privacy panels closed. At least one panel must be open for ventilation when using appliances. Failure to obey this warning could result in death or serious injury.

WARNING: FIRE OR ELECTRICAL SHOCK HAZARD. Failure to obey the following warnings could result in death or serious injury:

- Make sure there are no obstacles (such as wires or pipes) inside the RV roof or walls at the installation locations.
- Shut off the gas supply, disconnect the 120 VAC power from RV, and disconnect the positive (+) 12 VDC terminal from the supply battery before drilling or cutting into the RV.

WARNING: IMPACT OR CRUSH HAZARD.

Do not operate this screen room during periods of severe weather, such as high winds. Failure to obey this warning could result in death or serious injury.

WARNING: FIRE HAZARD.

Keep sources of heat and fire (such as barbecue grills or portable heaters) away from the screen room. Failure to obey this warning could result in death or serious injury.

NOTICE: Do not expose the screen room to adverse environmental conditions, corrosive agents, or other harmful conditions. Failure to obey this notice could result in damage to the product or property.

2 General Information

The Trim Line Screen Room is available in sizes to correspond with the various sizes of Trim Line Awnings.

The Trim Line Screen Room includes the following parts:

Included Parts

3 ft (0.9 m) and/or 4 ft (1.2 m) Front Panels¹

Left Side Panel

Right Side Panel

Rear Skirt

Wheel Cover

Storage Bag

3 in. (7.6 cm) Hook & Loop Strips

Snap Fasteners

Tent Stakes

¹ The number of 3 ft (0.9 m) and 4 ft (1.2 m) panels included will vary depending on the size of the Trim Line Screen Room.

Dometic recommends that the following tools and materials be used while installing the Trim Line Screen Room:

Recommended Tools

Pencil	1/8 in. (3 mm) Drill Bit
Measuring Tape	Center Punch
Phillips Screwdriver	Hammer or Mallet (for hook stakes)
Drill	

3 Intended Use

The compact and lightweight Trim Line Screen Room (hereinafter referred to as "unit" or "product") is designed and intended for mounting on pop-up tent campers.

The manufacturer accepts no liability for damage in the following cases:

- Faulty assembly or connection
- Damage to the product resulting from mechanical influences and excess voltage
- Alterations to the product without express permission from the manufacturer
- Use for purposes other than those described in the operating manual

Dometic Corporation reserves the right to modify appearances and specifications without notice.

4 Installation

This section describes how to install the Trim Line Screen Room onto a Trim Line Awning (sold separately).

Use care during installation so that the product does not become damaged.

- i** Park the camper on reasonably flat ground prior to installation of the product.

4.1 Open the Trim Line Awning

A Trim Line Awning must be installed prior to installation of the product.


Complete the following steps before installing the Trim Line Screen Room:

1. Open the Trim Line Awning bag and unroll the awning.
2. Unfold the square legs and rafter poles to set up the awning as shown in Figure 1.
3. Verify that the square legs are in a vertical orientation and that the awning fabric has a proper downward slope to facilitate water runoff.

⚠ CAUTION: LIFTING HAZARD.

Use the proper lifting technique and control when lifting and opening the Trim Line Awning. Failure to obey this caution could result in minor or moderate injury.

- i** For guidance on how to install the Trim Line Awning, consult the Dometic Trim Line Awning Installation and Operation Manual available on www.dometic.com.




1 Opening the Trim Line Awning

4. Measure the length of the Trim Line Awning with a measuring tape to determine whether you have the correct number of 3 ft (0.9 m) and 4 ft (1.2 m) front panels required to install the product.

4.2 Position the Screen Room

After the Trim Line Awning is installed, remove the product from its storage bag and line it up in position with the awning as shown in Figure 2.




2 Positioning the Screen Room

4.3 Install the Front Panels

Ensure the correct orientation of all panels prior to installation. The interior and exterior sides of all panels can be determined by locating the privacy panels; the privacy panel is always on the inside of the screen room.

Install the front panels by completing the following steps:

1. Slide the front panels into the awning roller tube from one end.
- i** Verify that the total panel widths selected match the width of the awning.
2. Zip together the front panels from the top to the bottom. See Figure 3.



3 Installing the Front Panels


4.4 Install the Side Panels

The left and right side panels zip onto the awning starting at the roller tube.

To install the side panels, complete these steps:

1. Zip the top of the side panels to the Trim Line Awning, starting at the front of the awning and moving towards the side of the camper.
2. Wrap the four hook and loop strips around each of the front square legs. See Figure 4.

i The front square legs will be outside of the screen room.




4 Installing the Side Panels

4.5 Fasten the Screen Room to the Camper

The flaps at the rear of each side panel are used to secure the product to the side of the camper.

To fasten the product to the camper, complete these steps:

1. Press the flaps at the rear of each side panel to the wall of the camper.
2. Starting at the top, align the top snap fasteners on each side flap to the wall of the camper.
3. Locate evenly spaced positions for the snap fasteners and mark these with a pencil.
4. Drill 1/8 in. (3 mm) holes and install the snap fasteners, using the provided hardware and recommended tools. Note that the protruding section will be pointing toward the side panel. See Figure 5.
5. Repeat steps 1 – 4 on the other side.




5 Fastening the Screen Room to the Camper

4.6 Attach the Rear Skirt

To attach the rear skirt to the screen room and the camper, complete these steps:

1. Align the rear skirt along the bottom of the camper where it attaches to the product, as shown in Figure 6.
2. Attach the plastic clips sewn on the rear skirt onto the frame ledge on the underside of the camper.
3. Attach the rear skirt to the side panels with hook and loop fasteners sewn into the screen room and the rear skirt.




6 Attaching the Rear Skirt

4.7 Secure the Screen Room to the Ground

For safety and stability, the product must be secured to the ground before use.

Secure the bottom of the product panels by driving hook stakes into the ground through the appropriate grommets. See Figure 7.




7 Securing the Screen Room to the Ground

4.8 Mount the Wheel Cover

To mount the wheel cover over the wheel opening, complete these steps:

1. Place the wheel cover in position to cover the wheel opening.
2. Mark the locations of the snap fasteners with a pencil.
3. With a 1/8 in. (3 mm) drill bit, pilot drill a shallow hole at each marked location.
4. Push a snap fastener through each drilled hole. The protruding section of the snap fastener should face down toward the ground.
5. Position the eyelet on the wheel cover underneath the protruding part of the snap fastener.
6. Push the wheel cover eyelet up and onto the snap fastener to connect the wheel cover. See Figure 8.



8 Mounting the Wheel Cover

7. Thread the 3 in. (7.6 mm) pieces of hook and loop strips through the openings sewn into the rear skirt and the wheel cover.

5 Operation

The Dometic Trim Line Screen Room is designed to expand the living space of campers, providing a place for dining, sleeping, or just relaxing.


The following sections describe how to use the privacy panels after the product has been installed and how to store the product when not in use.

5.1 Use the Privacy Panels

The privacy panels located on the inside of the front and side panels are useful for many purposes. Keeping the privacy panels closed will prevent anyone from seeing inside. Opening the panels will provide fresh air and ventilation.

To open the privacy panels, complete these steps:

1. Detach the privacy panel from the hook and loop fasteners at the bottom of the panel.
2. Roll the privacy panel upward toward the ceiling of the screen room.
3. Wrap the hook and loop fasteners at the top of the screen room around the rolled up privacy panel to hold the panel open. See Figure 9.



9 Opening the Privacy Panels



DANGER! CARBON MONOXIDE POISONING.

Do not operate any appliances (gas, combustion, etc.) venting into the screen room enclosure with the privacy panels closed. At least one panel must be open for ventilation when using appliances. Failure to obey this warning will result in death or serious injury.

To close the privacy panels, complete these steps:

1. Detach the hook and loop fasteners from the open privacy panel. The privacy panel should roll closed.
2. Use the hook and loop fasteners at the bottom of the panel to secure the privacy panel to the side of the screen room.

5.2 Store the Screen Room

The product comes in a weatherproof, zippered pouch for easy storage. The product should be stored when not in use.



The product should be dry before storing. Storing the product while wet could cause mold, mildew, unpleasant odors, and otherwise damage the material of the screen room.

6 Disposal



Place the packaging material in the appropriate recycling waste bins, whenever possible. Consult a local recycling center or specialist dealer for details about how to dispose of the product in accordance with all applicable national and local regulations.

LIMITED ONE-YEAR WARRANTY

LIMITED ONE-YEAR WARRANTY AVAILABLE AT WWW.DOMETIC.COM/WARRANTY.

IF YOU HAVE QUESTIONS, OR TO OBTAIN A COPY
OF THE LIMITED WARRANTY FREE OF CHARGE,
CONTACT:

DOMETIC CORPORATION
CUSTOMER SUPPORT CENTER
1120 NORTH MAIN STREET
ELKHART, INDIANA, USA 46514
1-800-544-4881 OPT 3

CUSTOMER SUPPORT

For the Authorized Service Center near you, call between 8:00 a.m. and 5:00 p.m., Monday through Friday, or contact the nearest Parts Distributor. Hours may vary.



Dometic RV Division Customer Support Center

1120 North Main Street
Elkhart, IN 46515
☎ +1 574-264-2131

AUSTRALIA

Dometic Australia Pty. Ltd.

1 John Duncan Court
Varsity Lakes QLD 4227
☎ 1800 212121
☎ +61 7 55076001
Mail: sales@dometic.com.au

AUSTRIA

Dometic Austria GmbH

Neudorferstraße 108
A-2353 Guntramsdorf
☎ +43 2236 908070
☎ +43 2236 90807060
Mail: info@dometic.at

BENELUX

Dometic Branch Office Belgium

Zincstraat 3
B-1500 Halle
☎ +32 2 3598040
☎ +32 2 3598050
Mail: info@dometic.be

BRAZIL

Dometic DO Brasil LTDA

Avenida Paulista 1754, conj. 111
SP 01310-920 Sao Paulo
☎ +55 11 3251 3352
☎ +55 11 3251 3362
Mail: info@dometic.com.br

DENMARK

Dometic Denmark A/S

Nordensvej 15, Taulov
DK-7000 Fredericia
☎ +45 75585966
☎ +45 75586307
Mail: info@dometic.dk

FINLAND

Dometic Finland OY

Mestartintie 4
FIN-01730 Vantaa
☎ +358 20 7413220
☎ +358 9 7593700
Mail: info@dometic.fi

FRANCE

Dometic SAS

ZA du Pré de la Dame Jeanne
B.P. 5
F-60128 Plailly
☎ +33 3 44633525
☎ +33 3 44633518
Mail: vehiculesdeloisirs@dometic.fr

GERMANY

Dometic WAECO International GmbH

Hollefeldstraße 63 · D-48282 Emsdetten
☎ +49 (0) 2572 879-195
☎ +49 (0) 2572 879-322
Mail: info@dometic-waeco.de

HONG KONG

Dometic Group Asia Pacific

Suites 2207-11 · 22/F · Tower 1
The Gateway · 25 Canton Road,
Tsim Sha Tsui · Kowloon
☎ +852 2 4611386
☎ +852 2 4665553
Mail: info@waeco.com.hk

HUNGARY

Dometic Zrt. Sales Office

Kerékgyártó u. 5.
H-1147 Budapest
☎ +36 1 468 4400
☎ +36 1 468 4401
Mail: budapest@dometic.hu

ITALY

Dometic Italy S.r.l.

Via Virgilio, 3
I-47122 Forlì (FC)
☎ +39 0543 754901
☎ +39 0543 754983
Mail: vendite@dometic.it

JAPAN

Dometic KK

Maekawa-Shibaura, Bldg. 2
2-13-9 Shibaura Minato-ku
Tokyo 108-0023
☎ +81 3 5445 3333
☎ +81 3 5445 3339
Mail: info@dometic.jp

MEXICO

Dometic Mx, S. de R. L. de C. V.

Circuito Médicos No. 6 Local 1
Colonia Ciudad Satélite
CP 53100 Naucalpan de Juárez
Estado de México
☎ +52 55 5374 4108
☎ +52 55 5393 4683
Mail: info@dometic.com.mx

NETHERLANDS

Dometic Benelux B.V.

Ecustraet 3
NL-4879 NP Etten-Leur
☎ +31 76 5029000
☎ +31 76 5029019
Mail: info@dometic.nl

NEW ZEALAND

Dometic New Zealand Ltd.

PO Box 12011
Penrose
Auckland 1642
☎ +64 9 622 1490
☎ +64 9 622 1573
Mail: customerservices@dometic.co.nz

NORWAY

Dometic Norway AS

Østerøyveien 46
N-3232 Sandefjord
☎ +47 33428450
☎ +47 33428459
Mail: firmapost@dometic.no

POLAND

Dometic Poland Sp. z o.o.

Ul. Puławska 435A
PL-02-801 Warszawa
☎ +48 22 414 3200
☎ +48 22 414 3201
Mail: info@dometic.pl

PORTUGAL

Dometic Spain, S.L.

Branch Office em Portugal
Rot. de São Gonçalo nº 1 – Esc. 12
2775-399 Carcavelos
☎ +351 219 244 173
☎ +351 219 243 206
Mail: info@dometic.pt

RUSSIA

Dometic RUS LLC

Komsomolskaya square 6-1
RU-107140 Moscow
☎ +7 495 780 79 39
☎ +7 495 916 56 53
Mail: info@dometic.ru

SINGAPORE

Dometic Pte Ltd

18 Boon Lay Way 06-140 Trade Hub 21
Singapore 609966
☎ +65 6795 3177
☎ +65 6862 6620
Mail: dometic@dometic.com.sg

SLOVAKIA

Dometic Slovakia s.r.o. Sales Office

Bratislava
Nádražná 34/A
900 28 Ivánka pri Dunaji
☎ / ☎ +421 2 45 529 680
Mail: bratislava@dometic.com

SOUTH AFRICA

Dometic (Pty) Ltd.

Regional Office
South Africa & Sub-Saharan Africa
2 Avalon Road
West Lake View Ext 11
Modderfontein 1645
Johannesburg
☎ +27 11 4504978
☎ +27 11 4504976
Mail: info@dometic.co.za

SPAIN

Dometic Spain S.L.

Avda. Sierra del Guadarrama, 16
E-28691 Villanueva de la Cañada
Madrid
☎ +34 91 833 60 89
☎ +34 900 100 245
Mail: info@dometic.es

SWEDEN

Dometic Scandinavia AB

Gustaf Melins gata 7
S-42131 Västra Frölunda
☎ +46 31 7341100
☎ +46 31 7341101
Mail: info@dometicgroup.se

SWITZERLAND

Dometic Switzerland AG

Riedackerstrasse 7a
CH-8153 Rümlang
☎ +41 44 8187171
☎ +41 44 8187191
Mail: info@dometic.ch

UNITED ARAB EMIRATES

Dometic Middle East FZCO

P. O. Box 17860
S-D 6, Jebel Ali Freezone
Dubai
☎ +971 4 883 3858
☎ +971 4 883 3868
Mail: info@dometic.ae

UNITED KINGDOM

Dometic UK Ltd.

Dometic House, The Brewery
Blandford St. Mary
Dorset DT11 9LS
☎ +44 344 626 0133
☎ +44 344 626 0143
Mail: customerservices@dometic.co.uk

USA & CANADA

Dometic Marine Division

2000 North Andrews Avenue
Pompano Beach, FL 33069
☎ +1 800-542-2477
☎ +1 954-979-4414
Mail: marinesales@dometic.com

Dometic RV Division

1120 North Main Street
Elkhart, IN 46515
☎ +1 574-264-2131

Dometic Sanitation Division

13128 St. Rte. 226
Big Prairie, OH 44611
☎ +1 800-321-9886
☎ +330-496-3097