


Explosion view



Spare Parts

Ref.No.	Pos	Qty	Description
4472006337	4021		SVC, TANK KIT WH-6EA
92105	4026		KIT, SVC INSULATION
90028	4048		KIT, SVC P&T VALVE ¾" 150PSI
4472006338	4088		SVC WIRES WH-6EA
93849	4100		KIT, SVC RELAY
92106	4114		KIT, SVC JUNCTION BOX
4472006336	4145		SVC, T-STAT/ECO WH-6EA
92107	4201		KIT, SVC POWER CORD

Piezas de recambio

N.º de ref.	Pos	Qty	Descripción
4472006337	4021		SVC, TANK KIT WH-6EA
92105	4026		KIT, SVC INSULATION
90028	4048		KIT, SVC P&T VALVE ¾" 150PSI
4472006338	4088		SVC WIRES WH-6EA
93849	4100		KIT, SVC RELAY
92106	4114		KIT, SVC JUNCTION BOX
4472006336	4145		SVC, T-STAT/ECO WH-6EA
92107	4201		KIT, SVC POWER CORD

Pièces de rechange

Nº de réf.	Pos	Qty	Description
4472006337	4021		SVC, TANK KIT WH-6EA
92105	4026		KIT, SVC INSULATION
90028	4048		KIT, SVC P&T VALVE ¾" 150PSI
4472006338	4088		SVC WIRES WH-6EA
93849	4100		KIT, SVC RELAY
92106	4114		KIT, SVC JUNCTION BOX
4472006336	4145		SVC, T-STAT/ECO WH-6EA
92107	4201		KIT, SVC POWER CORD

