

↗ DOMETIC POWER & CONTROL CONNECT



Interact System Package for LMC Musica, LMC Vivo/Hymer/Eriba Nova

EN

Interact System Package

Service Manual

DE


Interact System Package

Serviceanleitung

© 2020 Dometic Group. The visual appearance of the contents of this manual is protected by copyright and design law. The underlying technical design and the products contained herein may be protected by design, patent or be patent pending. The trademarks mentioned in this manual belong to Dometic Sweden AB. All rights are reserved.


Overview cabinet / Übersicht Schrank



Circuit diagram / Schaltplan

Installing gateway / Gateway installieren

3




4



Installing gateway / Gateway installieren



Installing modem / Modem installieren




When the DCP is removed, these LEDs must be visible (fig. 7):

- Left: Power LED Interact LTE modem
- Right: LED Interact gateway


Wenn das DCP entnommen wird, müssen diese LEDs erkennbar sein (Abb. 7):

- Links: Power LED des Interact LTE Modems
- Rechts: LED des Interact Gateways


Connect gateway cable to LTE modem / Gateway-Kabel mit LTE-Modem verbinden




Connect power cable of LTE modem / Power-Kabel des LTE-Modems anschließen




**Connect power cable to the distribution circuit board /
Power-Kabel an der Verteilerplatine anschließen**



Installing antenna / Antenne installieren




Screw antenna cable on the modem / Antennenkabel am Modem aufschrauben



NOTICE! ACHTUNG!

If necessary secure the cable against slipping /
Kabel ggf. gegen Verrutschen sichern


Connect gateway cable to gateway / Gateway-Kabel ans Gateway anschließen



NOTICE! ACHTUNG!

If necessary secure the cable against slipping /
Kabel ggf. gegen Verrutschen sichern


**Connect gateway cable to the distribution circuit board /
Gateway-Kabel an der Verteilerplatine anschließen**




NOTICE! ACHTUNG!

Pay attention to the contacting /
Kontaktierung beachten

Connecting control panel / Bedienfeld anschließen




**Remove cable that was connected to the DCP /
Kabel abziehen, das mit dem DCP verbunden war**




**Connect this cable to the adapter /
Dieses Kabel mit dem Adapter verbinden**




**Connect the other end of the cable to the distribution circuit board /
Das andere Ende des Kabel an der Verteilerplatine anschließen**




**Connect the display extension cable to the distribution board /
Display Extension Kabel an Verteilerplatine anschließen**




**Connect the other end of the display extension cable to the DCP /
Anderes Ende des Display Extension Kabel an DCP anschließen**



Installing distribution board / Verteilerplatine installieren



Attach the distribution board and cable to the vehicle / Befestigen der Verteilerplatine und Kabel an Fahrzeug



Installing type plate / Typenschild installieren



Mobile living made easy.



dometic.com

**YOUR LOCAL
DEALER**

dometic.com/dealer

**YOUR LOCAL
SUPPORT**

dometic.com/contact

**YOUR LOCAL
SALES OFFICE**

dometic.com/sales-offices

A complete list of Dometic companies, which comprise the Dometic Group, can be found in the public filings of:
DOMETIC GROUP AB Hemvärnsgatan 15 SE-17154 Solna Sweden