






FENDER

IT	Istruzioni di montaggio	ET	Paigaldusjuhend	PT	Instruções de Montagem
EN	Fitting instructions	FI	Asennusohje	RO	Instrucțiuni de montare
DE	Montageanleitung	HR	Uputa za sastavljanje	RU	Инструкции по установке
FR	Instructions de montage	HU	A felszerelés módja	SK	Návod na montáž
ES	Instrucciones de montaje	LT	Pritvirtinimo instrukcijos	SL	Navodila za pritrjevanje
BG	инструкции за сглобяване	LV	Stiprināšanas instrukcija	SV	Monteringsanvisning
CS	Návod na montáž	NL	Montagehandleiding	TK	Uydurma talimat
DA	Monteringsvejledning	NO	Monteringsanvisning	ZH	裝修指導
EL	Οδηγίες συναρμολόγησης	PL	Instrukcja montażu	AR	كتيب التعليمات








IT) Componenti (Inclusi) | EN) Components (Included) | FR) Composants (Comprises)
 DE) Die Komponenten (im Lieferumfang enthalten) | ES) Componentes (Incluido)





 x2	 x2	 x2	 5mm 0.2" x1
--	--	--	--

IT) Ricambi (A Richiesta) | EN) Spare Parts (Made to order) | DE) E Teile (auf Anfrage)
 FR) Pièces de rechange (Sur commande) | ES) Piezas de recambio (Previa solicitud)

 x1	 x1	 x2	 x2
700052500000		700007900000	700007800000
 5mm 0.2" x1	 x1	 x2	
700025000000	700031000000	700030900000	


1

x2






2


x4




3




4



x4






x2






5

x2





Car Manual 		
		
Fender	3,7kg / 8.1lb	MAX 90kg / 198 lb
Fender XL	3,9kg / 8.6lb	




MAX LOAD : 90kg 198lb

$$\text{A} + \text{B} \leq \text{MAX LOAD}$$

DYNAMIC

MAX PAYLOAD



STATIC



2,5x MAX PAYLOAD

