





	EN Read the instructions! FR Lisez les instructions ! ES Lea las instrucciones.		EN Not to be used by very young children (0–3 years)! FR Ne doit pas être utilisé par les très jeunes enfants (0–3 ans) ! ES No puede ser usada por niños muy pequeños (de 0 a 3 años).
	EN Do not insert pins! FR Ne pas insérer d'épingles ! ES No introduzca pasadores.		EN Do not bleach. FR Ne pas blanchir. ES No use lejía.
	EN Do not wash. FR Ne pas laver. ES No la lave.		EN Do not dry clean. FR Ne pas nettoyer à sec. ES No la lave en seco.
	EN Do not tumble dry. FR Ne pas sécher au sèche-linge. ES No seque en secadora.		

EN Operating manual

Please read these instructions carefully and follow all instructions, guidelines, and warnings included in this product manual in order to ensure that you install, use, and maintain the product properly at all times. These instructions MUST stay with this product.

By using the product, you hereby confirm that you have read all instructions, guidelines, and warnings carefully and that you understand and agree to abide by the terms and conditions as set forth herein. You agree to use this product only for the intended purpose and application and in accordance with the instructions, guidelines, and warnings as set forth in this product manual as well as in accordance with all applicable laws and regulations. A failure to read and follow the instructions and warnings set forth herein may result in an injury to yourself and others, damage to your product or damage to other property in the vicinity. This product manual, including the instructions, guidelines, and warnings, and related documentation, may be subject to changes and updates. For up-to-date product information, please visit documents.dometic.com, dometic.com.

- Safety instructions**
- DO NOT OPERATE THE HEATING PAD IF IT IS VISIBLY DAMAGED.
 - If this heating pad's power cable is damaged, it must be replaced by the manufacturer, a service agent or a similarly qualified person in order to prevent safety hazards.
 - This heating pad may only be repaired by qualified personnel. Improper repairs can lead to considerable hazards.
 - Do not use the heating pad in wet conditions or submerge in any liquid. Store in a dry place.
 - Before starting the heating pad, ensure that the power cable and the plug are dry.
 - Disconnect the heating pad from the power supply
 - Before each cleaning and maintenance
 - After every use
 - CAREFULLY EXAMINE THE COVER BEFORE EACH USE. DISCARD THE PAD IF THE COVERING SHOWS ANY SIGN OF DETERIORATION.
 - DO NOT USE THE DEVICE WHILE SLEEPING.
 - This device can be used by children older than 3 years and younger than 8 years under supervision and with the control always set to minimum temperature value.
 - This device can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the device in a safe way and understand the hazards involved.
 - CHILDREN UNDER THE AGE OF 3 YEARS ARE NOT TO USE THIS DEVICE DUE TO THEIR INABILITY TO REACT TO OVERHEATING.
 - THIS PAD IS NOT TO BE USED BY OR ON AN INVALID, SLEEPING OR UNCONSCIOUS PERSON, OR A PERSON WITH POOR BLOOD CIRCULATION UNLESS CAREFULLY ATTENDED.
 - The heating pad must not be used by persons insensitive to heat and other very vulnerable persons who are unable to react to overheating.
 - DO NOT USE THE HEATING PAD ON AREAS OF INSENSITIVE SKIN OR DIRECTLY ON BARE SKIN.
 - BURNS CAN OCCUR REGARDLESS OF CONTROL SETTINGS, CHECK THE SKIN UNDER THE HEATING PAD FREQUENTLY.

- Children should be supervised to ensure that they do not play with the device.
- Check that the voltage specification on the data plate corresponds to that of the energy supply.
- Do not place the device near naked flames or other heat sources (heaters, direct sunlight, gas ovens etc.).
- Do not use any blankets, cushions or other covers on the heating pad.
- DO NOT ROLL UP OR FOLD THE HEATING PAD DURING OPERATION OR FOR STORAGE.
- DO NOT PLACE HEAVY OBJECTS ON THE HEATING PAD - AVOID SHARP FOLDS.
- DO NOT INSERT ANY SHARP OBJECTS INTO THE HEATING PAD (E.G. SAFETY PINS OR OTHER METALLIC MEANS).
- NEVER PULL THE PLUG OUT OF THE SOCKET BY THE CABLE.
- DO NOT USE THE CABLE AS A HANDLE.
- LOOP THE CABLE LOOSELY WHEN STORING, TIGHT WRAPPING MAY DAMAGE THE CABLE AND INTERNAL PARTS.

Intended use

The heating pad is intended to warm your body or certain individual parts of the body. The heating pad is **not** intended for

- Commercial or industrial use
- Medical use in hospitals, medical practices, etc

This product is only suitable for the intended purpose and application in accordance with these instructions.

This manual provides information that is necessary for proper installation and/or operation of the product. Poor installation and/or improper operating or maintenance will result in unsatisfactory performance and a possible failure.


- The manufacturer accepts no liability for any injury or damage to the product resulting from:
- Incorrect assembly or connection, including excess voltage
 - Incorrect maintenance or use of spare parts other than original spare parts provided by the manufacturer
 - Alterations to the product without express permission from the manufacturer
 - Use for purposes other than those described in this manual
- Dometic reserves the right to change product appearance and product specifications.

Technical description

The heating pad is equipped with an automatic shut-off function. This switches off the heat supply after approx. 45 min. of continuous operation.

The heating pad is fitted with a safety thermostat that regulates the heat and prevents overheating of the heating pad by automatically switching off the heating pad as soon as the maximum temperature of 55 °C is reached.

- Using the heating pad**
- CAUTION! Risk of injury**
- Before each use, test the temperature with the back of your hand.
 - Prolonged use at the highest level may cause burns. Set the heating pad to the lowest setting (Low) for continuous use.
 - If you feel any pain, switch off the device immediately.
- Proceed as shown to use the heating pad (fig. **3** to fig. **4**).
- Note:** Ensure that the capacity of the mobile power supply (e.g. USB-Powerbank) matches the required capacity of the heating pad.



dometic.com		
YOUR LOCAL DEALER	YOUR LOCAL SUPPORT	YOUR LOCAL SALES OFFICE
dometic.com/dealer	dometic.com/contact	dometic.com/sales-offices
A complete list of Dometic companies, which comprise the Dometic Group, can be found in the public filings of: DOMETIC GROUP AB Hemvångsgatan 15 SE-17154 Solna Sweden		
4445103654 2022-06-29		


Replacing the fuse

► To replace the fuse proceed as shown (fig. **5**).

- Cleaning and maintenance**
- CAUTION! Electrocutation hazard**
- After cleaning, wait until the heating pad is completely dry before plugging in and connecting to the power supply. Do not use or store when damp!
 - Cleaning and user maintenance may not be carried out by unsupervised children
- NOTICE! Damage hazard**
- Allow the heating pad to cool down completely before cleaning, folding or storing.
 - Do not wash the heating pad in the washing machine or under running water.
 - Do not tumble dry.
 - Do not use sharp or hard objects or cleaning agents for cleaning as these may damage the product.

- Examine the device frequently for signs of wear or damage. If there are such signs, if the device has been misused or does not work, return it to the supplier before switching it on again
- Clean the heating pad regularly and as soon as it becomes dirty with a dry soft brush or a damp cloth.

Problem	Possible reason	Solution
The heating pad does not work. The power button does not illuminate.	The heating pad does not receive any power.	► Check that the plug is fully inserted into the power source. ► Check that the adapter is fully connected. ► Plug in another device to check the correct operation of the power source.
The heating pad does not work. The power button illuminates.	The heating pad does not receive enough current.	Check that the voltage supply provides a sufficient current (see chapter "Technical data").
The heating pad switches off.	The automatic shut-off function has responded.	Switch on the heating pad again.
	Risk of overheating! The safety thermostat has responded.	Allow the heating pad to cool down completely before switching on again.



EN Heating Pad Operating manual
FR Coussin chauffant Notice d'utilisation
ES Almohadilla eléctrica Instrucciones de uso

- Disposal**
- Place the packaging material in the appropriate recycling waste bins wherever possible.
- Consult a local recycling center or specialist dealer for details about how to dispose of the product in accordance with the applicable disposal regulations.
- The product can be disposed free of charge.

Technical data		
Voltage:	5 V $\overline{---}$	12 V $\overline{---}$
Max. power consumption:	11 W	22 W
Rated current:	2.3 A	1.8 A
Fuse amp rating:	5 A	
Connection cable length:	900 mm	
Adapter cable length:	500 mm	
Dimensions:	fig. 2	
Weight:	0.35 kg	
Inspection/ certification		

FR Notice d'utilisation

Veuillez lire et suivre attentivement l'ensemble des instructions, directives et avertissements figurant dans ce manuel afin de vous assurer que vous installez, utilisez et entretenez le produit correctement à tout moment. Ces instructions DOIVENT rester avec le produit.

En utilisant ce produit, vous confirmez expressément avoir lu attentivement l'ensemble des instructions, directives et avertissements et que vous comprenez et acceptez de respecter les modalités et conditions énoncées dans le présent document. Vous acceptez d'utiliser ce produit uniquement pour l'usage et l'application prévus et conformément aux instructions, directives et avertissements figurant dans le présent manuel, ainsi qu'à toutes les lois et réglementations applicables. En cas de non-respect des instructions et avertissements figurant dans ce manuel, vous risquez de vous blesser ou de blesser d'autres personnes, d'endommager votre produit ou d'endommager d'autres biens à proximité. Le présent manuel du produit, y compris les instructions, directives et avertissements, ainsi que la documentation associée peuvent faire l'objet de modifications et de mises à jour. Pour obtenir des informations actualisées sur le produit, veuillez consulter le site documents.dometic.com, dometic.com.

- Consignes de sécurité**
- N'UTILISEZ PAS LE COUSSIN CHAUFFANT S'IL PRÉSENTE DES DÉGÂTS VISIBLES
 - Si le câble d'alimentation du coussin chauffant est endommagé, il doit être remplacé par le fabricant, un agent de service ou une personne de qualification similaire, afin d'éviter tout danger.

