

## Replacing a Solid Black Sail Switch


### **WARNING: ELECTRICAL SHOCK AND/OR FIRE HAZARD**

Always disconnect the unit from power before servicing.  
Maintenance **must** be done by a qualified service person only.  
Failure to obey this warning could result in death or serious injury.

These Service Kit Instructions (SKI) contain important supplementary information or notifications for the furnace sail switch. It is not intended to provide all information, instruction, and/or safety messaging related to the product. For complete information, refer to the product manuals.

This type of sail switch has a slightly thinner electrical terminal. To make a proper connection on an older DF Series furnaces, gently squeeze the wire harness connector with pliers to close the gap slightly.

Do **not** use wire cutters to squeeze the wire harness connector. Do **not** squeeze the wire harness connector so hard that it completely closes on the terminal.



## Replacing a Solid Black Sail Switch


### **WARNING: ELECTRICAL SHOCK AND/OR FIRE HAZARD**

Always disconnect the unit from power before servicing.  
Maintenance **must** be done by a qualified service person only.  
Failure to obey this warning could result in death or serious injury.

These Service Kit Instructions (SKI) contain important supplementary information or notifications for the furnace sail switch. It is not intended to provide all information, instruction, and/or safety messaging related to the product. For complete information, refer to the product manuals.

This type of sail switch has a slightly thinner electrical terminal. To make a proper connection on an older DF Series furnaces, gently squeeze the wire harness connector with pliers to close the gap slightly.

Do **not** use wire cutters to squeeze the wire harness connector. Do **not** squeeze the wire harness connector so hard that it completely closes on the terminal.



## Replacing a Solid Black Sail Switch


### **WARNING: ELECTRICAL SHOCK AND/OR FIRE HAZARD**

Always disconnect the unit from power before servicing.  
Maintenance **must** be done by a qualified service person only.  
Failure to obey this warning could result in death or serious injury.

These Service Kit Instructions (SKI) contain important supplementary information or notifications for the furnace sail switch. It is not intended to provide all information, instruction, and/or safety messaging related to the product. For complete information, refer to the product manuals.

This type of sail switch has a slightly thinner electrical terminal. To make a proper connection on an older DF Series furnaces, gently squeeze the wire harness connector with pliers to close the gap slightly.

Do **not** use wire cutters to squeeze the wire harness connector. Do **not** squeeze the wire harness connector so hard that it completely closes on the terminal.



## Replacing a Solid Black Sail Switch

### **WARNING: ELECTRICAL SHOCK AND/OR FIRE HAZARD**

Always disconnect the unit from power before servicing.  
Maintenance **must** be done by a qualified service person only.  
Failure to obey this warning could result in death or serious injury.

These Service Kit Instructions (SKI) contain important supplementary information or notifications for the furnace sail switch. It is not intended to provide all information, instruction, and/or safety messaging related to the product. For complete information, refer to the product manuals.

This type of sail switch has a slightly thinner electrical terminal. To make a proper connection on an older DF Series furnaces, gently squeeze the wire harness connector with pliers to close the gap slightly.

Do **not** use wire cutters to squeeze the wire harness connector. Do **not** squeeze the wire harness connector so hard that it completely closes on the terminal.

