



## !!! IMPORTANT !!!

### Installation Check List

- Carefully remove unit from it's packaging and inspect for any damage that may have occurred in transit. If damage is found, report it within the first 24 hours of taking delivery. Please report this damage to your point of purchase and the carrier responsible for handling.
  
- Be sure that all parts have been included. These parts will consist of black mounting screws and a bottom flange piece.  
**Note:** On T18 and T22 units, the bottom mounting flange is factory installed. On T42 units, the bottom mounting flange is furnished as a separate part. If your particular application calls for the unit to sit on the floor when installed, this bottom mounting flange may not be required.
  
- Stand unit upright for a minimum of 8 hours (before applying power) to allow compressor oils to settle.  
**Note:** Though we state on our packaging to always keep unit upright, we cannot control how the carrier handles our boxes. This also applies if unit has been set on it's side to affix the bottom flange piece.
  
- Carefully review all wiring diagrams included. Wire your unit directly to the appropriate 12 VDC power source.
  
- Make sure adequate ventilation is provided to assure proper operation of your unit. Refer to the Installation And Operating Instructions for details.
  
- Once all of the above have been satisfied, you are ready to enjoy your new Refrigerator. For best results, allow unit to run for 24 hours before loading with goods.

Form No. 3309440.000 11/04  
(French 3309444.002)  
©2004 Dometic Corporation  
Lagrange, IN 46761

