

SERVICE BULLETIN

Dometic GmbH, In der Steinwiese 16, D-57074 Siegen


RM 8400/01/05, 8500/01/05/50/51/55, RML 8550/51/55, RMS 8400/01/05/60/61/65, RMS 8500/01/05/50/51/55

Door lock with lighting


The door lock with lighting 241 3267-01/0 is no longer available.
Instead of this door lock depending on the door hang one of the following door locks have to be used:

241 3267-41/6, Door lock with lighting, left hang
241 3267-51/5, Door lock with lighting, right hang

At fridges, which control the lighting with a sensor (295 1380-11/8 or 295 1380-51/4) inside of the control panel, the sensor must not be removed.



Door lock with lighting,
left hang,
spare part number 241 3267-41/6



Door lock with lighting,
right hang,
spare part number 241 3267-51/5