


NOTE: IT IS VERY IMPORTANT TO READ AND FOLLOW THE DIRECTIONS IN THE INSTALLATION INSTRUCTIONS REAR WALL TEMPLATE.

This template is for locating the horizontal exhaust cutout. Do not use this template for vertical or recirculation exhaust.

1. Tape the template to the rear wall.
2. Use a saber or keyhole saw to cut out the shaded area F. through the rear wall.
3. Remove the template from the rear wall.
4. RETURN TO AND PROCEED WITH THE INSTALLATION INSTRUCTIONS.

Part Number: 525049000070



CAUTION -IF EXHAUST ADAPTOR IS POSITIONED OUTSIDE RECOMMENDED DIMENSION, GREASE-LADEN AIR WILL DISCHARGE INTO HOUSE STRUCTURE.

## REAR WALL TEMPLATE

30" MINIMUM WIDTH REQUIRED

178