
# > DOMETIC POWER & CONTROL PORTABLE BATTERY PACK





#### PLB15


# Copyright


© 2024 Dometic Group. The visual appearance of the contents of this manual is protected by copyright and design law. The underlying technical design and the products contained herein may be protected by design, patent or pending patent. The trademarks mentioned in this manual belong to Dometic Sweden AB. All rights are reserved.


# **List of Figures**











# **English**

# 1 Important notes

Please read these instructions carefully and follow all instructions, guidelines, and warnings included in this product manual in order to ensure that you install, use, and maintain the product properly at all times. These instructions MUST stay with this product.

By using the product, you hereby confirm that you have read all instructions, guidelines, and warnings carefully and that you understand and agree to ablied by the terms and conditions as set forth herein. You agree to use this product only for the intended purpose and application and in accordance with the instructions, guidelines, and warnings as set forth in this product manual as well as in accordance with all applicable laws and regulations. A failure to read and follow the instructions and warnings set forth herein may result in an injury to yourself and others, damage to your product or damage to other property in the vicinity. This product manual, including the instructions, guidelines, and warnings, and related documentation, may be subject to changes and updates. For up-to-date product information, please visit documents. Gometic.com.

# 2 Explanation of symbols



#### WARNING!

Indicates a hazardous situation that, if not avoided, could result in death or serious injury.



#### CAUTION!

Indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.



#### NOTICE!

Indicates a situation that, if not avoided, can result in property damage.

# 3 Safety instructions

# **General safety**



#### WARNING! Electrocution hazard

- Do not operate the device if it is visibly damaged.
- The device may only be repaired by qualified personnel. Improper repairs can lead to considerable hazards.
  - Do not disassemble the device.
  - Do not modify or adapt any of the components in any way.
- Only use accessories and spare parts that are recommended by the manufacturer.
- Do not use the device in wet conditions or submerge in any liquid. Store in a dry place.
- Switch off the device and disconnect it from the power supply before each cleaning or maintenance and after every use.



#### WARNING! Risk of injury

Batteries contain aggressive and caustic acids. Avoid battery fluid coming into contact with your body. If your skin does come into contact with battery fluid, wash that part of your body thoroughly with water. If you sustain any injuries from acids, contact a doctor immediately.



#### WARNING! Health hazard

- Do not open or damage batteries or allow them to enter the environment, as they contain toxic and environmentally harmful heavy metals.
- This device is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the device by a person responsible for their safety.
- Electrical devices are not toys. Always keep and use the device out of the reach of very young children.
- Children must be supervised to ensure that they do not play with the device.
- Cleaning and user maintenance shall not be made by children without supervision.



#### **NOTICE!** Damage hazard

- Before start-up, check that the voltage specification on the data plate is the same as that of the power supply.
- Ensure that other objects cannot cause a short circuit at the contacts of the device.
- Ensure that the negative and positive poles never come into contact.
- Do not use the cables as a handle.

## Operating the device safely



#### CAUTION! Explosion hazard

- Do **not** operate the device under the following conditions:
  - In salty, wet or damp environments
  - In the vicinity of corrosive fumes
  - In the vicinity of combustible materials
  - In areas where there is a risk of gas or dust explosion
- Never attempt to charge a frozen or defective battery. Place the battery pack in a frost-free area and wait until the battery has acclimatised to the ambient temperature.
- · Do not place the device near heat sources (heaters, direct sunlight, gas ovens, etc.).
- Do not smoke, use an open flame, or cause sparking near the battery pack.
- Do not leave the device unattended when in use.



#### CAUTION! Electrocution hazard

- Before starting the device ensure that the power supply cable and the plug are dry and the plug is free from rust or dirt.
- When working on electrical systems ensure that there is somebody close at hand who can help in emergencies.

- Lay the cables so that they cannot be damaged by sharp edges, doors, or the hood. Do not
  lay any cable so that it is heavily kinked. Crushed cables can lead to serious injury.
- · Do not disconnect any cables when the device is still in use.



#### CAUTION! Fire hazard

- Do not drop, hit, or apply excessive force to the device to avoid damage to external and internal parts.
- · Do not place the device near flammable materials.



#### CAUTION! Risk of injury

When positioning the device ensure that all cables are suitably secured to avoid any form of trip hazard.



#### **NOTICE!** Damage hazard

- Ensure that the air inlets and outlets of the device are not covered.
- · Ensure a good ventilation.
- Set up the device in a dry location where it is protected against splashing water.
  - Never pull the plug out of the socket by the cable.
- Loop the cable loosely when storing, tight wrapping may damage the cable and internal parts.
- Avoid deep discharge of the device.

## 4 Related documents



Find the detailed operating manual online at gr.dometic.com/be3qNF.

### 5 Intended use

The portable battery pack is intended for charging digital mobile devices (e.g., cell phones, tablets, laptops, cameras, etc.), or operation of 12 V devices (e.g., air pumps, cooling boxes, and other outdoor equipment), and for use as a flashlicht.

The portable battery pack is suitable for outdoor use, e.g., touring.

The portable battery pack is **not** suitable for

- Parallel connection with other portable battery packs
- Commercial use

This product is only suitable for the intended purpose and application in accordance with these instructions.

This manual provides information that is necessary for proper installation and/or operation of the product. Poor installation and/or improper operating or maintenance will result in unsatisfactory performance and a possible failure.

The manufacturer accepts no liability for any injury or damage to the product resulting from:

- · Incorrect installation, assembly or connection, including excess voltage
- · Incorrect maintenance or use of spare parts other than original spare parts provided by the manufacturer
- Alterations to the product without express permission from the manufacturer
- Use for purposes other than those described in this manual

Dometic reserves the right to change product appearance and product specifications.

# 6 Operation

Proceed as shown:

- > Charging the battery pack:
  - Fig. 1 on page 3
  - > Checking the state of charge:
    - Fig. 2 on page 3
  - > Using the LED flashlight:
    - Fig. 3 on page 4
  - > Charging devices via USB:
    - Fig. 4 on page 4
  - > Operating 12 V devices:
    - Fig. 5 on page 5

# 7 Disposal



Recycling packaging material: Place the packaging material in the appropriate recycling waste bins wherever possible.



Recycling products with non-replaceable batteries, rechargeable batteries, or light sources:

- If the product contains any non-replaceable batteries, rechargeable batteries, or light sources, you don't have to remove them before disposal.
- If you wish to finally dispose of the product, ask your local recycling center or specialist dealer for details about how to do this in accordance with the applicable disposal regulations.



# dometic.com

# YOUR LOCAL DEALER

dometic.com/dealer

# YOUR LOCAL SUPPORT

dometic.com/contact

# YOUR LOCAL SALES OFFICE

dometic.com/sales-offices

A complete list of Dometic companies, which comprise the Dometic Group, can be found in the public filings of: **DOMETIC GROUP AB** • Hemvärnsgatan 15 • SE-17154 Solna • Sweden